

Evolution User Guide



Terminal Web User Interface iDirect 9-Series, iQ-Series,
and 3315 Series

Evolution

iDX 4.3.x

Revision 1

January 31, 2023



© 2023 ST Engineering iDirect, Inc. dba iDirect and/or its affiliates. All rights reserved.

All rights reserved. Reproduction in whole or in part without permission is prohibited. Information contained herein is subject to change without notice. The specifications and information regarding the products in this document are subject to change without notice. While every effort has been made to ensure the accuracy of the statements, information and recommendations in this document, they are provided without warranty of any kind, express, or implied. Users must take full responsibility for their application of any products. Trademarks, brand names and products mentioned in this document are the property of their respective owners. All such references are used strictly in an editorial fashion with no intent to convey any affiliation with the name or the product's rightful owner.

ST Engineering iDirect is a global leader in satellite communications (satcom) providing technology and solutions that enable its customers to expand their business, differentiate their services and optimize their satcom networks. Through the merger with Newtec, a recognized industry pioneer, the combined business unites over 35 years of innovation focused on solving satellite's most critical economic and technology challenges, and expands a shared commitment to shaping the future of how the world connects. The product portfolio, branded under the names **iDirect** and **Newtec**, represents the highest standards in performance, efficiency and reliability, making it possible for its customers to deliver the best satcom connectivity experience anywhere in the world. ST Engineering iDirect is the world's largest TDMA enterprise VSAT manufacturer and is the leader in key industries including broadcast, mobility and military/government.

Company Website: www.idirect.net | Main Phone: 703.648.8000

TAC Contact Information: Phone: 703.648.8151 | Email: tac@idirect.net | Website: www.support.idirect.net

iDirect Government created in 2007, is a wholly owned subsidiary of ST Engineering iDirect and was formed to better serve the U.S. government and defense communities. In 2019, iDirect Government acquired Glowlink Communications Technology, Inc.

Company Website: www.idirectgov.com | Main Phone: 703.648.8118

TAC Contact Information: Phone: 703.648.8111 | Email: tac@idirectgov.com | Website: partnerportal.idirectgov.com

Document Name: UG_TerminalWUI_Evo_4.3.x_T0001413_Rev_1_27_Jan_2023

Document Part Number: T0001413

Revision History

The following table shows all revisions for this document. To determine if this is the latest revision, check the Technical Assistance Center (TAC) Web site. Refer to [Getting Help on page x](#) for TAC access information.

Revision	Date	Updates
1	January 31, 2023	Initial release of the document for iDX Release 4.3.x.

Contents

Revision History	iii
Figures	ix
Tables	xi
Aboutxiii
Intended Audiencexiii
Manual Contentsxiii
Related Documentsxiv
Related Training Servicesxiv
Getting Helpxiv
Chapter 1 Introduction	1
1.1 Supported Routers	1
1.2 Terminal Web User Interface	1
1.2.1 Terminal WUI Features	1
1.3 Terminal Web User Interface Login	2
1.4 Connecting to the Terminal WUI	2
1.4.1 Manually Configuring the Windows Host to Connect to the Satellite Router	3
1.5 Starting a Terminal WUI Session	5
1.5.1 Simulated LEDs	6
Chapter 2 Terminal Web User Interface	7
2.1 Dashboard	7

2.2	Details Menu	9
2.2.1	Satellite Interface	9
2.2.1.1	Satellite Interface - Reporting and Configuration	9
2.2.2	Terminal/Device	11
2.2.2.1	Terminal Device - Reporting and Configuration	11
2.2.3	LAN Interface	12
2.2.3.1	LAN Interface - Reporting (LAN Ports).	12
2.2.3.2	LAN Interface - IP Configuration VLANs.	14
2.2.3.3	LAN Interface - BGP Peer Status	15
2.2.4	External Equipment	15
2.2.4.1	External Equipment - Antenna	16
2.2.4.2	External Equipment - LNB	16
2.3	Commissioning	17
2.3.1	Commissioning Wizard	17
2.3.2	Commissioning Details	18
2.3.3	Angle Calculator	19
2.3.4	Antenna Pointing.	20
2.3.5	Cross Polarization/P1dB	21
2.4	Administration	22
2.4.1	Downlink Configuration	23
2.4.2	Loading Packages using the Terminal WUI	24
2.4.3	Loading Configuration Files using the Terminal WUI	24
2.4.3.1	Loading the downstream_config.json File	25
2.4.3.2	Loading the Options File	25
2.5	COTP (Comm-On-The-Pause)	26
2.5.1	Using the Terminal WUI	27
Chapter 3 Commissioning a Terminal		29
3.1	Introduction	30
3.2	Software Upgrade	31
3.3	Manual Antenna Pointing (without OpenAMIP)	31
3.3.1	Selecting a Site.	31

3.3.2	Assembly	31
3.3.3	Orientation	31
3.3.4	Magnetic Variation.	32
3.3.5	Sighting Antenna Azimuth	33
3.3.6	Elevation Offset	33
3.3.7	Using the Terminal WUI	34
3.4	Cross-Polarization	36
3.4.1	Overview	36
3.4.2	Satellite Access.	37
	Preparation	37
3.4.3	Performing Cross-Pol Adjustment	38
3.4.4	After Securing the Antenna	39
3.4.5	Establish 1dB Compression Point and Maximum Power	39
	Preparation	39
	Determine 1dB Compression Point.	41
3.4.6	Using the Terminal WUI	42
3.5	Acquire the Network	43
3.5.1	Overview	43
3.5.2	Initial Acquisition	44
3.6	Set Power.	46
3.6.1	Overview	46
	The Reference Carrier	46
	Maximum Power	47
3.6.2	Set Power	47
	Setting TDMA Initial Power and Maximum Power	47
3.7	16QAM Output Back-Off	49
 Appendix A Acronyms and Abbreviations.		53
 Appendix B Remote Locking.		57
B.1	Locking the Remote	58
B.2	Configuring the Network Key	58
B.3	The Remote Lock Process	58

B.4	Performing a Temporary Lock	62
B.5	Performing a Soft Lock	63
B.6	Performing a Hard Lock.	64
B.7	Unlocking a Soft Lock	65
B.8	Non-Warranty RMA Required to Remove Remote Locks	67
Appendix C Using the Unified Recovery Program (URP)		69
C.1	URP Overview	69
	Evolution Software Installation Details	70
C.2	Downloading a New Software Package	70
C.3	Accessing the URP	70
C.4	Installing Evolution Software on a Modem.	71

Figures

Figure 1-1.	WUI Log-In Screen	2
Figure 1-2.	Network and Sharing Center	3
Figure 1-3.	Local Area Connection Status	3
Figure 1-4.	Local Area Connection Properties Window	4
Figure 1-5.	Internet Protocol Version 4 Properties	4
Figure 1-6.	Terminal WUI Dashboard	5
Figure 1-7.	LED Indicators	6
Figure 2-1.	Dashboard Menu	7
Figure 2-2.	Details Menu	9
Figure 2-3.	Satellite Interface - Reporting and Configuration	9
Figure 2-4.	Terminal Device - Reporting and Configuration	11
Figure 2-5.	LAN Interface - Reporting (LAN Ports)	12
Figure 2-6.	LAN Interface - IP Configuration VLANs	14
Figure 2-7.	BGP Peer Status - All VLANs	15
Figure 2-8.	BGP Peer Status - Specific VLAN	15
Figure 2-9.	External Equipment - Antenna	16
Figure 2-10.	External Equipment - LNB	16
Figure 2-11.	Commissioning Menu	17
Figure 2-12.	Commissioning Details	18
Figure 2-13.	Angle Calculator	19
Figure 2-14.	Antenna Pointing	20
Figure 2-15.	Cross Polarization	21
Figure 2-16.	Administration Menu	22
Figure 2-17.	Administration - Software & Configuration	23
Figure 2-18.	Downlink Configuration	23
Figure 2-19.	Manage Software Packages	24
Figure 2-20.	Loading Configuration Files	25
Figure 2-21.	COTP Menu	26
Figure 2-22.	COTP - Set Remote Location	26
Figure 2-23.	Set Remote Location - Configure Downstream	27
Figure 2-24.	Antenna Pointing	28
Figure 2-25.	COTP - Set Remote Location Completion	28
Figure 3-1.	Commissioning Menu	30
Figure 3-2.	Commissioning Wizard	30
Figure 3-3.	Example: Magnetic Declination	32
Figure 3-4.	Antenna Elevation Offset	34
Figure 3-5.	Antenna Pointing	34
Figure 3-6.	Configure Downstream	35

Figure 3-7.	Antenna Pointing	35
Figure 3-8.	Terminal WUI Cross Polarization Page	37
Figure 3-9.	Sample Transfer Characteristic.	40
Figure 3-10.	Adjust Transmit Power	41
Figure 3-11.	Cross Polarization test	42
Figure 3-12.	Exit Commissioning Mode	43
Figure 3-13.	Commissioning Complete.	43
Figure 3-14.	iMonitor Probe: Changing the Satellite Router Transmit Power	45
Figure 3-15.	Initial Power in Probe and iBuilder	47
Figure 3-16.	iBuilder Transmit Properties: TDMA	48
Figure 3-17.	Setting Up OBO Value Before Commissioning.	49
Figure 3-18.	CRC Monitoring on iMonitor	50
Figure 3-19.	C/N0 verification for 16QAM requirement.	51
Figure B-1.	Login Page Showing Username as "developer"	59
Figure B-2.	Lock Type Drop-Down List Options	59
Figure B-3.	Netkey, Fingerprint, and Confirmation Word.	60
Figure B-4.	Warning at Page Bottom	60
Figure B-5.	Confirm Netlock Pop-Up Window	61
Figure B-6.	Final Lock Status	61
Figure B-7.	Soft Locked Screen.	66
Figure B-8.	Unlocked State	66
Figure C-1.	URP Home Page	71
Figure C-2.	URP Home Page - Install Evolution	71
Figure C-3.	Choose the Evolution Software Package	72
Figure C-4.	Upload the Evolution Software Package	72
Figure C-5.	Evolution Software Package Upload Complete.	73
Figure C-6.	Evolution Software Package Upload Confirmation	73
Figure C-7.	Select Modem Partition.	74
Figure C-8.	Reconfigure the eMMC	74
Figure C-9.	Evolution Software Package Installation.	75
Figure C-10.	URP Started Installation Message	75
Figure C-11.	Viewing Syslog Messages	76
Figure C-12.	Syslog Messages - Installation Complete	76
Figure C-13.	Reset Button.	77
Figure C-14.	Evolution Software Package Boot Release.	77
Figure C-15.	URP Started Installation Message	78

Tables

Table 2-1.	Dashboard Menu Items	8
Table 2-2.	Satellite Interface - Reporting and Configuration Field Descriptions	10
Table 2-3.	Terminal Device - Reporting and Configuration Field Descriptions	12
Table 2-4.	LAN Interface - Reporting (LAN Ports) Field Descriptions.	13
Table 2-5.	IP Configuration VLANs Field Descriptions	14
Table 2-6.	LNB Field Descriptions	17
Table 2-7.	Commissioning Details	18
Table 2-8.	Angle Calculator	19
Table 2-9.	Antenna Pointing.	21
Table 2-10.	Cross Polarization	21

About

This chapter contains the following sections:

- [Intended Audience](#)
- [Manual Contents](#)
- [Related Documents](#)
- [Related Training Services](#)
- [Getting Help](#)

Intended Audience

The *Terminal WUI User Guide* is for iDirect network operators or installers to connect directly to a 9-Series, iQ Series (iQ Desktop, iQ 200 Board, iQ 200 Rackmount and iQ LTE), and 3315 Series (MDM3315, SMB3315) satellite routers. This may include installers responsible for Terminal commissioning, network operators connecting remotely, or on-site personnel working with iDirect to troubleshoot network problems.

Manual Contents

In addition to the information in this chapter, this manual also includes the following:

- [Chapter 1, Introduction on page 1](#), provides information about what the terminal WUI is, the supported routers, the login details, and the LED information.
- [Chapter 2, Terminal Web User Interface](#) provides information on how to connect to the terminal WUI and provides information on the terminal WUI and explains each one of the tabs in-detail.
- [Chapter 3, Commissioning a Terminal](#) provides information on how to commission a new remote using the terminal WUI.
- [Appendix A, Acronyms and Abbreviations](#) provides a basic list of acronyms and abbreviations.
- [Appendix B, Remote Locking](#) provides information about soft, temporary, and hard locking for iQ Series and 3315 Series remotes.

Related Documents

The following iDirect documents are available at <http://tac.idirect.net> and contain related information. Consult these documents for additional information about iDirect systems and equipment:

- *Quick Start Guide (QSG), included in package with router*
- *Installation, Support, and Maintenance (ISM) Guide*
- *iDirect Evolution™ Software Release Notes*
- *iBuilder User Guide*
- *iMonitor User Guide*
- *iDX Technical Reference Guide*

Related Training Services

iDirect offers scheduled classroom training at various global training centers, as well as eLearning, in the installation, operation, maintenance and management of iDirect satellite networks. For training course descriptions and available training dates visit the iDirect web site *Training and Services* at: <http://www.idirect.net/Training-and-Services.aspx> or call +1 (800) 648-8240 for class registration and information.

Getting Help

The iDirect Technical Assistance Center (TAC) and the iDirect Government Technical Assistance Center (TAC) are available to provide assistance 24 hours a day, 365 days a year. Software user guides, installation procedures, FAQs, and other documents that support iDirect and iDirect Government products are available on the respective TAC Web site:

- Access the iDirect TAC Web site at <http://support.idirect.net>
- Access the iDirect Government TAC Web site at <http://tac.idirectgov.com>

The iDirect TAC may be contacted by telephone or email:

- Telephone: 703.648.8151
- E-mail: tac@idirect.net

The iDirect Government TAC may be contacted by telephone or email:

- Telephone: 703.648.8111
- Email: tac@idirectgov.com

iDirect and iDirect Government produce documentation that are technically accurate, easy to use, and helpful to our customers. Please assist us in improving this document by providing feedback. Send comments to:

- iDirect: techpubs@idirect.net
- iDirect Government: techpubs@idirectgov.com

For sales or product purchasing information contact iDirect Corporate Sales at the following telephone number or e-mail address:

- Telephone: 703.648.8000
- E-mail: sales@idirect.net

1 Introduction

This chapter provides a general overview of the Terminal Web User Interface (WUI).

- [Section 1.1, Supported Routers on page 1](#)
- [Section 1.2, Terminal Web User Interface on page 1](#)
- [Section 1.3, Terminal Web User Interface Login on page 2](#)
- [Section 1.4, Connecting to the Terminal WUI on page 2](#)
- [Section 1.5, Starting a Terminal WUI Session on page 5](#)

1.1 Supported Routers

The Terminal WUI is supported on the iDirect 9-Series, 3315 Series, and iQ Series Satellite Routers.



NOTE: Pulse Width Modulation (PWM) is not supported for the iQ Series satellite routers.

1.2 Terminal Web User Interface

The Terminal Web User Interface (WUI) provides users with secure means to monitor satellite routers from the local area network (LAN) side.

The Terminal WUI also provides configuration and real-time status and statistical information about the satellite routers. Terminal WUI provides interaction with the satellite router, enabling configuration, commissioning, and monitoring without a direct connection with the iVantage NMS. The level of functionality available to the user is determined by the login access (admin or user).

1.2.1 Terminal WUI Features

Terminal WUI provides the following features:

- LED indicators that display real-time status of the satellite router
- A dashboard view of high-level satellite router information (for example, displays if a satellite router is in network or locked to the satellite)

- A status and monitoring view that provides status and monitoring information about the satellite router in real-time for modem information, events, Ethernet receive and transmit connections, and Internet Protocol (IP) configuration and information
- Administration tools for loading software packages and options files
- A wizard for commissioning new remotes

1.3 Terminal Web User Interface Login

The Terminal WUI supports two levels of log-in; a generic user level, and an administrator level. The log-in screen is shown in [Figure 1-1](#).




Figure 1-1. WUI Log-In Screen

The default login credentials for the two configured user accounts admin and user are:

Username: admin

Password: iDirect



NOTE: The password specified above is just an example and the actual password is the one that is configured in iBuilder. Username and password are both case sensitive.

1.4 Connecting to the Terminal WUI

Terminal WUI may be used at any time to access the Satellite Routers. All that is necessary is the IP address assigned to the satellite router and a physical Ethernet connection to the LAN port.

Default factory settings for the Satellite Routers are shown below:

- LAN IP Address: 192.168.0.1
- Subnet mask: 255.255.255.0

1.4.1 Manually Configuring the Windows Host to Connect to the Satellite Router

1. Click Start > Control Panel > Network and Sharing Center.




Figure 1-2. Network and Sharing Center

2. Under **View your active networks**, click **Local Area Connection**. The **Local Area Connection Status** window is displayed.




Figure 1-3. Local Area Connection Status

3. Click **Properties**.

The **Local Area Connection Properties** window is displayed.




Figure 1-4. Local Area Connection Properties Window

4. Select the **Internet Protocol Version 4 (TCP/IPv4)** check box, and click **Properties**.

The **Internet Protocol Version 4 (TCP/IPv4) Properties** window is displayed.




Figure 1-5. Internet Protocol Version 4 Properties

5. Select **Use the following IP address**, and enter the following:
 - **IP address**-Enter an unused IP address on the same subnet as the router.
 - **Subnet mask**-Enter the IP address, and the subnet mask is automatically retrieved.
 - **Default gateway**-This field is optional.
6. Click **OK**.

1.5 Starting a Terminal WUI Session

The Web view is compatible with Internet Explorer 10 and above, or latest Mozilla Firefox and Chrome browsers.

The Terminal WUI has two default user accounts:

- **admin**: Provides full access to WUI functionality
- **user**: Provides restricted access to WUI functionality

To launch the Terminal WUI, perform the following:

1. Connect the personal computer (PC) LAN port to the satellite router local area network (LAN) Port 1 using an Ethernet cable.

2. Launch the Web browser of choice.

On the address bar, enter the IP address of the satellite router into the address field.

The login terminal as seen in [Figure 1-1](#) is displayed.

3. Enter the Username and Password as follows:

Username - admin

Password - iDirect

4. Click **Login**.

The Web User Interface dashboard as seen in [Figure 1-6](#) is displayed.




Figure 1-6. Terminal WUI Dashboard

1.5.1 Simulated LEDs

The menus in the Terminal WUI display simulated LEDs (see [Figure 1-7](#)). For detailed information on the LED color and function, see the routers *Installation, Support, and Maintenance Guide*.




Figure 1-7. LED Indicators

2 Terminal Web User Interface

This chapter introduces the Terminal Web User Interface (WUI) provided on iDirect Satellite Routers. It contains the following sections:

- [Section 2.1, Dashboard on page 7](#)
- [Section 2.2, Details Menu on page 9](#)
- [Section 2.3, Commissioning on page 17](#)
- [Section 2.4, Administration on page 22](#)
- [Section 2.5, COTP \(Comm-On-The-Pause\) on page 26](#)

2.1 Dashboard

The Dashboard page provides key information about the Satellite Routers that have an established connection.

The Dashboard page is the default landing page of the Terminal Web UI. See [Figure 2-1](#).




Figure 2-1. Dashboard Menu



NOTE: The Dashboard for 9-Series remotes is different from the Dashboards for the iQ Series and the 3315 Series remotes. The figure above shows the Dashboard for iQ Series/3315 Series remotes.

Table 2-1 displays the field descriptions for the dashboard.

Table 2-1. Dashboard Menu Items

Menu Item	Sub-menu Item	Description
System Status		Displays the overall status of the Terminal system.
Link Status		Displays the status of all the network links.
	Network Status	Displays if the router is in the network.
	Satellite Receiver	Displays if the router is enabled to receive information.
	Satellite Transmitter	Displays if the router is enabled to transmit information.
	Receive SNR	Displays the SNR of the received downstream.
Terminal Configuration		Displays the configuration of the terminal.
	Model Type	Displays the model type of the terminal.
	Serial Number	Displays the serial number of the terminal.
	Software Version	Displays the current software version that is running.
Receive SNR		Displays the receive carriers signal to noise ratio.
Device Status		Displays the status of the terminal.
	CPU Load	Displays the current CPU load.
	Memory Use	Displays the current memory in use.
Take me to...	View Satellite Details	Displays the details of the satellite.
	View Terminal Details	Displays the details of the terminal.
	View current LAN throughput	Displays the details of the LAN ports.
Terminal Events		Displays the events sent to the NMS.
	Up Time	Displays the amount of time falcon was running when an event occurred.
	Description	Displays the content of the event.

2.2 Details Menu

Use the Details Menu page to report and view satellite, terminal, LAN, and external equipment information.



NOTE: iDX Release 4.1.6.0 adds **BGP Peer Status** to the Lan Interface page.



Figure 2-2. Details Menu

2.2.1 Satellite Interface

The Satellite Interface displays information on the satellite.

2.2.1.1 Satellite Interface - Reporting and Configuration

Click **Details > Satellite Interface > Reporting & Configuration** to view the satellite information.

Satellite Interface - Reporting & Configuration

Modem State	
Network	WAITING_FOR_RX_LOCK
Main Satellite Receiver	Waiting for Demod Lock
Satellite Transmit	MUTED

Receiver 1 State	
Downlink Center Frequency	IF: 1000 MHz / RF: 1000 MHz
Symbol Rate	119000 Kbps
Receiver Role	MAIN
Beam ID	-
Receiver Status	Waiting for Demod Lock
Receiver Composite Power	-100 dBm
Receiver SNR	-10 dB

Transmit State	
Point of report	Power at the terminal's IF port
Initial Transmit Power	-5 dBm
Maximum Power	0 dBm
Power relative to the Nominal Carrier	-14.70 dBm
Reference Carrier - Symbol Rate	7500000 Sps/s
Reference Carrier - C/N threshold	6 dB

Transmit State - Nominal Carrier	
Uplink Center Frequency	IF: 1100 MHz / RF: 1100 MHz
Symbol Rate	7500 Kbps
Modulation	QPSK
FEC Rate	3/4
Payload Size	170 Bytes

Figure 2-3. Satellite Interface - Reporting and Configuration

Table 2-2 displays the field descriptions for the satellite interface.

Table 2-2. Satellite Interface - Reporting and Configuration Field Descriptions

Menu Item	Sub-menu Item	Sub-menu Item	Description
Satellite Interface- Reporting and Configuration			
	Modem State		Displays the status of the modem.
		Network	Displays if the modem is connected to the network.
		Main Satellite Receive	Displays one of the following: <ul style="list-style-type: none"> • Locked • Waiting for NCR Lock—Third and final stage of the receiver lock. • Waiting for Demod Lock—Second stage of the receiver lock. • Waiting for Tuner Locktuner_locked—First stage of the receiver lock. • Off
		Satellite Transmit	Displays the state as either MUTED or UNMUTED. The transmitter can be muted by any of the following conditions: <ul style="list-style-type: none"> • not in network • external mute signal • OpenAMIP mute command NOTE: The above conditions are not exhaustive.
	Transmit State		Displays the status of the transmitter.
		Point of Report	Indicates the point for which the terminal's transmit power is reported. This point could be either at the output of the satellite router's transmit output, or at the BUC flange.
		Initial Transmit Power	Displays the initial transmit power of the satellite router.
		Maximum Power	Displays the configured max power of the satellite router's transmitter.
		Power Relative to the Nominal Carrier	Displays the current transmit power relative to the nominal carrier.
		Reference Carrier - Symbol Rate	Displays the symbol rate of the reference carrier.
		Reference Carrier - C/N threshold	Displays the threshold of the reference carrier.
	Transmit State - Nominal Carrier		
		Uplink Center Frequency	Displays the uplink center frequency of the carrier.
		Symbol Rate	Displays the symbol rate of the carrier.

Menu Item	Sub-menu Item	Sub-menu Item	Description
		Modulation	Displays the modulation.
		FEC Rate	Displays the FEC rate.
		Payload Size	Displays the payload size.
	Receive 1 State		Displays the status of the first receiver.
		Downlink Center Frequency	Displays the router listening frequency.
		Symbol Rate	Displays the symbol rate.
		Receiver Role	Displays the receiver role as MAIN or AUXILIARY.
		Beam ID	Displays the Beam ID.
		Receiver Status	Displays the status of the receiver.
		Receive Composite Power	Displays the total power at the front end.
		Receiver SNR	Displays the signal noise ratio measured in the terminal.

2.2.2 Terminal/Device

The Terminal Device page displays details of the terminal.

2.2.2.1 Terminal Device - Reporting and Configuration

Click **Details** > **Terminal/Device** > **Reporting & Configuration** to view the terminal information.




Figure 2-4. Terminal Device - Reporting and Configuration

Table 2-3 displays the field descriptions for the terminal device.

Table 2-3. Terminal Device - Reporting and Configuration Field Descriptions

Menu Item	Sub-menu Item	Sub-menu Item	Description
Terminal/Device-	Reporting and Configuration		Displays information about the terminal or device.
	Terminal Information		Displays information about the terminal.
		Model Type	Displays the model type of the terminal.
		Serial Number	Displays the serial number.
		Software Version	Displays the software version that is active on the terminal.
	Device Status		Displays the status of the terminal.
		CPU Load	Displays the CPU load.
		Memory Use	Displays the amount of memory used by the device.
	Geographical Location		Displays the geographic location of the terminal.
		Longitude	Displays the longitude in decimal notation E or W.
		Latitude	Displays the latitude in decimal notation N or S.

2.2.3 LAN Interface

The LAN Interface page displays information on ports and VLANs.

2.2.3.1 LAN Interface - Reporting (LAN Ports)

Click **Details** > **LAN Interface** > **Reporting (Ports)** to view information on ports.




Figure 2-5. LAN Interface - Reporting (LAN Ports)

Table 2-4 displays the field descriptions for the LAN interface.

Table 2-4. LAN Interface - Reporting (LAN Ports) Field Descriptions

Menu Item	Sub-menu Item	Sub-menu Item	Description
LAN Interface - Reporting (LAN Ports)			Displays information about the terminal Ethernet port(s).
Port Configuration			Displays the status of the port.
Status			Displays the status of the port as connected, disconnected or disabled.
Speed			Displays the speed of the port in 10, 100, or 1000 Mbps.
MAC Address			Displays the MAC address of the LAN interface.
Port VLAN Assignment			Displays information about the various Ports and VLANs assigned to those ports.
VLANs			Displays the VLANs configured on the port.
Untagged VLAN			Displays the VLAN that is not tagged with any VLAN ID.
Received			
Data Received			Displays the number of packets received.
Received Frames			Displays the frames of ethernet data received through the port.
Dropped Frames			Displays the number of dropped frames.
Error Frames			Displays the number of error frames.
Sent			
Data Sent			Displays the number of packets sent.
Sent Frames			Displays the frames of ethernet data sent through the port.
Dropped Frames			Displays the number of dropped frames.
Error Frames			Displays the number of error frames.

2.2.3.2 LAN Interface - IP Configuration VLANs

Click **Details** > **LAN Interface** > **IP Configuration VLANs** to view the VLAN information.




Figure 2-6. LAN Interface - IP Configuration VLANs

[Table 2-5](#) displays the field descriptions for the VLANs.

Table 2-5. IP Configuration VLANs Field Descriptions

Menu Item	Sub-menu Item	Description
IP Interface		Displays the IP address/mask of the Ethernet interface of the management VLAN.
	IP Address	Displays the IP address.
	Subnet Mask	Displays the subnet mask address.
DHCP Config		Displays the DHCP configuration information.
	DHCP Mode	Displays the DHCP mode as either Server, Client, or Relay.
	Lease Range Start	Displays the DHCP servers lease range start.
	Lease Range End	Displays the DHCP servers lease range end.
	Lease Time	Displays the DHCP servers lease time.
	Primary DHCP	Displays the primary DHCP server.
	Secondary DHCP	Displays the secondary DHCP server.
	Default Gateway	Displays the default gateway.
DNS Config		
	Local DNS Name	Displays the local DNS name.
	Local IP Address	Displays the local IP address.
	Primary DNS Name	Displays the DNS server name.
	Primary IP Address	Displays the primary DNS server IP address.
	Secondary DNS Name	Displays the DNS secondary name.
	Secondary IP Address	Displays the secondary DNS server IP address.

2.2.3.3 LAN Interface - BGP Peer Status

Click **Details > LAN Interface > BGP Peer Status** to view status information for all configured VLANs. Alternatively, click on the **VLAN ID** pull-down menu to view status information for a specific VLAN.

The screenshot shows the 'LAN Interface - BGP Peer Status' page with the 'VLAN ID' dropdown menu set to 'All'. The table below displays the BGP peer status for all configured VLANs.

VLAN ID	IP Address	AS	BGP Status(Up/Down)
103	192.168.103.22	1003	Up
103	192.168.103.62	1006	Down
203	192.168.203.22	2000	Down
203	192.168.203.62	2000	Up
203	192.168.203.63	2001	Up
203	192.168.203.64	2002	Down
203	192.168.203.65	2000	Up
203	192.168.203.88	2000	Up
203	192.168.203.98	2000	Up
203	192.168.203.96	2000	Up
203	192.168.203.99	2000	Up

Figure 2-7. BGP Peer Status - All VLANs

The screenshot shows the 'LAN Interface - BGP Peer Status' page with the 'VLAN ID' dropdown menu set to '203'. The table below displays the BGP peer status for the specific VLAN 203.

VLAN ID	IP Address	AS	BGP Status(Up/Down)
203	192.168.203.22	2000	Down
203	192.168.203.62	2000	Up
203	192.168.203.63	2001	Up
203	192.168.203.64	2002	Down
203	192.168.203.65	2000	Up
203	192.168.203.88	2000	Up
203	192.168.203.98	2000	Up
203	192.168.203.96	2000	Up
203	192.168.203.99	2000	Up

Figure 2-8. BGP Peer Status - Specific VLAN

2.2.4 External Equipment

The External Equipment page displays information on the BUC, LNB, and Antenna.

2.2.4.1 External Equipment - Antenna



Figure 2-9. External Equipment - Antenna

2.2.4.2 External Equipment - LNB

Click **Details** > **External Equipment** > **LNB** to view the LNB information.




Figure 2-10. External Equipment - LNB

[Table 2-6](#) displays the field descriptions for the LNB.

Table 2-6. LNB Field Descriptions

Menu Item	Sub-menu Item	Sub-menu Item	Description
External Equipment -LNB			
	LNB Information		Displays LNB information.
		Translation	Displays the LNBs LO frequency.
		Spectral Inversion	Displays the value as True or False if enabled in the options file. This is the function of the BUC or LNB where it mirror images the signal that helps in decoding the signal.
		Reference	Displays the LNB's reference clock in MHz.
		Tone enabled	Displays the value as True or False if enabled in the options file. This is the control tone to the LNB.
		DC Voltage	Displays the power output to the LNB in volts.

2.3 Commissioning

This section describes the procedure to bring a terminal into network using the Terminal WUI. Commissioning is the process of preparing a terminal to be able to properly transmit in a network. See [Figure 2-11](#).




Figure 2-11. Commissioning Menu

2.3.1 Commissioning Wizard

For information on commissioning the terminal using the commissioning wizard, see [Commissioning a Terminal on page 29](#).

2.3.2 Commissioning Details

The tab displays the commissioning details of the terminal.




Figure 2-12. Commissioning Details

[Table](#) provides the descriptions for the fields in the commissioning details page.

Table 2-7. Commissioning Details

Menu Item	Sub-menu Item	Description
PN Test Results		
	Mode	Displays the mode as Pseudo-random Noise (PN).
	IF Frequency	Displays the IF frequency.
	RF Frequency	Displays the RF frequency.
	Symbol Rate	Displays the symbol rate of the carrier.
Power Levels		
	P1dB	Displays the P1dB level at which the BUC output begins to saturate.
	Maximum TX Power	Displays the maximum allowed transmit power.
	BUC rated power	Displays the BUC rated power.
RX Parameters		
	IF Frequency	Displays the IF frequency.
	RF Frequency	Displays the RF frequency.
	Symbol Rate	Displays the symbol rate of the carrier.
Location Data		
	Time	Displays the time taken to retrieve the longitude and latitude time during commissioning.
	Latitude	Displays the latitude in decimal notation N or S.

Menu Item	Sub-menu Item	Description
	Longitude	Displays the longitude in decimal notation E or W.
	Altitude	Displays the altitude of the terminal.

2.3.3 Angle Calculator

Use this tab to calculate the antenna settings to be used for initial, and manual pointing of the antenna.

Figure 2-13. Angle Calculator

Table provides the descriptions for the fields in the angle calculator page.

Table 2-8. Angle Calculator

Menu Item	Sub-menu Item	Description
Remote Position		
	Remote Latitude	Displays the latitude of the terminal.
	Remote Latitude Direction	Indicates whether the latitude is in the North or South direction.
	Remote Longitude	Displays the longitude of the terminal.
	Remote Longitude Direction	Indicates whether the longitude is in the North or South direction.
Antenna		
	Elevation Offset	The offset angle of the antenna (that is, the degree to which the mechanical axis of the antenna feed is different from the optical axis).
Calculated coarse antenna pointing		
	Elevation Actual	The calculated elevation of the mechanical axis of the antenna reflector.
	Azimuth True	The calculated true azimuth to the spacecraft, referenced to geographic North (does not include magnetic variation).

Table 2-8. Angle Calculator (continued)

Menu Item	Sub-menu Item	Description
	Polarization Offset	The calculated polarization skew angle.
	Elevation True	The angle to the spacecraft if the antenna had no offset at all. This value is derived from the site geo-coordinates and the spacecraft longitude. It does not include antenna offset.
Satellite Position		
	Satellite Longitude	Displays the longitude of the satellite.
	Satellite Longitude Direction	Displays the satellite longitude direction.

2.3.4 Antenna Pointing

Use this tab to set the parameters needed to receive a downstream that will be used to fine-point the antenna.




Figure 2-14. Antenna Pointing

Table 2-9 provides the descriptions for the fields in the antenna pointing page.

Table 2-9. Antenna Pointing

Menu Item	Description
Receiver	Displays the receiver type.
RF Frequency	Describes the RF frequency used.
Modulation	Displays the modulation options.
Symbol Rate	Displays the symbol rate selected by the installer.
Roll-Off	Displays the roll-off value.
Satellite Longitude	Displays the longitude of the satellite.
Satellite Longitude Direction	Displays the satellite longitude direction.

2.3.5 Cross Polarization/P1dB

Use this option to control the transmission of a test signal (either a CW or a PN modulated carrier) that can be used to find the P1dB compression point of the BUC or to adjust the polarization alignment and check the separation between the cross polarizations.




Figure 2-15. Cross Polarization

Table 2-10 describes the fields in the cross polarization page.

Table 2-10. Cross Polarization

Menu Item	Sub-menu Item	Description
Transmit Frequency		

Table 2-10. Cross Polarization (continued)

Menu Item	Sub-menu Item	Description
	RF Uplink Frequency	Displays the Transmit RF Uplink Frequency at which the router would transmit.
	BUC LO Frequency	Displays the BUC LO Frequency that is automatically populated from the terminal option file.
	L-Band Tx Frequency	Displays the L-Band Tx Frequency that is calculated based on the RF uplink frequency and BUC LO frequency.
Transmit Power		
	Adjust L-Band Transmit Power	Displays the power value set by the installer.
Modulator		
	Modulation	Displays the modulation options.
	Symbol Rate	Displays the symbol rate selected by the installer.
	Rolloff	Displays the rolloff factor. The rolloff factor can be 5% or 20% in PN test only.
	Receiver	Displays the receiver type.

2.4 Administration

The Administration page displays the software and configuration information. See [Figure 2-16](#).




Figure 2-16. Administration Menu

Under the **Administration** tab, only one option, **Software and Configuration**, is available. Use this tab to load the latest software packages or option files.

The **Administration - Software & Configuration** page will display when selecting the **Software and Configuration** option (see [Figure 2-17](#)).

Administration - Software & Configuration

Receiver 1

Mode	Manual Downstream	
IF Frequency	1,600.0000000	MHz
Symbol Rate	41,000.0000000	Ksps
Rolloff	20	%

Save

Manage Software Packages Reboot Terminal

Upload Software Package: Select Files...

Software	Package Name	Creation Date	Version	
active1	Evolution Remote	12/31/1969	0.0.0-unknown	Activate Software Package
active0	Evolution Remote	12/31/1969	0.0.0-unknown	Activate Software Package
factory	Evolution Remote	07/10/2017	20.0.0-312	Software package is currently active

Configuration Files

Description	Filename	Version	Date	Size		
iDirect manual configuration	downstream_config.json		12/31/1969	373	Upload Configuration File	Download Configuration File
iDirect remote configuration	falcon.opt		08/02/2017	3876	Upload Configuration File	Download Configuration File

Figure 2-17. Administration - Software & Configuration

2.4.1 Downlink Configuration

The downlink configuration is available on the **Administration - Software & Configuration** page under **Receiver 1** section (see [Figure 2-18.](#))

Receiver 1

Mode	Manual Downstream	
IF Frequency	1,600.0000000	MHz
Symbol Rate	119,000.0000000	Ksps
Rolloff	5	%

Save

Figure 2-18. Downlink Configuration

Use this section to manually configure the downlink parameters as follows:

- **IF Frequency** – The IF downlink center frequency for the downstream carrier.
- **Symbol Rate** – The rate of downstream carrier in kilo symbols per second (Ksps)
- **Rolloff** – roll-off factor value predefined as: 5%, 10%, and 20%

Once the changes have been made, click **Save** to push the changes to the terminal. Note that, the changes will take effect immediately and only temporary while the terminal remains active. Once the terminal is reset, it will load from the stored options file.

2.4.2 Loading Packages using the Terminal WUI

Use the Terminal WUI to upload the latest software packages. To upload the latest software package, perform the following:

1. On the terminal WUI, click **Administration > Software and Configuration**. The **Administration - Software & Configuration** page is displayed.
2. Under **Manage Software Packages** (see [Figure 2-19.](#)), click **Select Files** and browse to the location where the packages are stored on the local system and click **Open**. The upload progress is seen on the right-hand corner. The software package will be uploaded and listed under **Upload Software Package**.




Figure 2-19. Manage Software Packages

The current Partition number, Type, Description, and Version are displayed.

3. To activate the latest software, click **Activate Software Package** against the required partition.
4. After updating the latest software on the partition, a message to reboot the terminal is displayed. Click **Reboot Terminal** to restart the terminal.

2.4.3 Loading Configuration Files using the Terminal WUI

The configuration files can be uploaded to or downloaded from the terminal under the **Configuration Files** section.

There are two types of configuration files that are being used by the terminal, each with different usage:

- **downstream_config.json** – This file consists of a set of configuration parameters for the downlink (frequency, symbol rate, and roll-off factor). Changes in the **downstream_config.json** are only temporary and take effect immediately after uploading it to the terminal.
- **falcon.opt** – This file consists of a complete set of options for the terminal. The changes made to this option file are applied only after a reboot.

Configuration Files

Description	Filename	Version	Date	Size		
iDirect manual configuration	downstream_config.json		12/31/1969	374	Upload Configuration File	Download Configuration File
iDirect remote configuration	falcon.opt		01/31/2018	5145	Upload Configuration File	Download Configuration File

Figure 2-20. Loading Configuration Files

All the configuration files that are currently uploaded are displayed with the Description, Filename, Version, Date, and Size.

2.4.3.1 Loading the downstream_config.json File

To load the downstream_config.json file, perform the following:

1. On the terminal WUI, click **Administration** → **Software and Configuration**. The **Administration - Software & Configuration** page is displayed. See [Figure 2-20](#).
2. Under **Configuration Files - iDirect manual configuration**, click **Download Configuration File** to download the existing configuration file or **Upload Configuration File** to upload a new configuration file from the local server.

After uploading the downstream_config.json file, the changes (based on the values set in the file) will take effect immediately without having to reboot the terminal.



CAUTION: DO NOT restart the terminal after uploading the latest **downstream_config.json** file. Rebooting the terminal will cause the terminal to lose the downstream configuration updates in the **downstream_config.json** file because it will boot up using the current **falcon.opt** file.

2.4.3.2 Loading the Options File

To load the falcon.opt options file, perform the following:

1. On the terminal WUI, click **Administration** > **Software and Configuration**. The **Administration - Software & Configuration** page is displayed. See [Figure 2-20](#).
2. Under **Configuration Files**, click **Download Configuration File** to download the existing configuration file and click **Upload Configuration File** to upload a new configuration file from your system.

After uploading the latest **falcon.opt** on the partition, the terminal must be restarted for the changes to take place. Click **Reboot Terminal** to restart the terminal.



NOTE: The terminal must be restarted so that it will boot up with the latest falcon.opt file.

2.5 COTP (Comm-On-The-Pause)



NOTE: COTP tab is only available for the iQ Series satellite routers.

The COTP is a new feature introduced in iDX Release 4.1.1 and available only for the iQ Series satellite routers. This feature allows a VSAT user to move a terminal to a new location by simply entering the new location information and re-pointing the antenna.

The COTP page provides the Set Remote Location function. See [Figure 2-21](#).




Figure 2-21. COTP Menu

Under the **COTP** tab, only one option, **Set Remote Location**, is available. Use this tab to set the remote location in COTP mode.

The **Set Remote Location** page will display when selecting the **Set Remote Location** option (see [Figure 2-17](#)).

Figure 2-22. COTP - Set Remote Location

2.5.1 Using the Terminal WUI

On the terminal WUI, click **COTP > Set Remote Location**. On the **Coarse Antenna Pointing** page (Figure 2-22). Update the **Remote Position** section based on the current location of the satellite terminal. Click **Save Remote Location and Continue**.

On the **Configure Downstream** page (Figure 2-23), ensure the frequency and other parameters are correct. Click **Continue**. To change the frequency or any other parameter, click **Administration > Software and Configuration**.

Receiver	Receiver 1
RF Frequency	1,500.0000 MHz (950 - 33000)
Modulation	ACM
Symbol Rate	45,000.00 Ksps (1000 - 119000)
Rolloff	20 %

Figure 2-23. Set Remote Location - Configure Downstream



NOTE: Before pointing the antenna to the satellite, ensure the highlighted step in the **Fine Antenna Pointing** page is followed. Always point the antenna to clear sky first and mark the measurement.

On the **Fine Antenna Pointing** page (Figure 2-24), physically position the antenna to point to the satellite.




Figure 2-24. Antenna Pointing

Point the antenna (satellite dish) towards the clear sky. Click **Start Antenna Pointing** to initialize the graphing of the received signal. Physically start rotating/moving the antenna towards the direction of the satellite (as calculated in the coarse pointing page). The graph starts to display an increase in received signal. Direct the antenna to the direction where the graph displays the highest voltage.

When the **Demod Lock Status** displays **Locked**, click **Continue**.

Set Remote Location for COTP is now completed (Figure 2-25), click **Return to dashboard** to go back to the main dashboard.




Figure 2-25. COTP - Set Remote Location Completion

3 Commissioning a Terminal

This chapter describes how to commission a satellite router. Commissioning is the process of preparing a satellite router to be able to properly transmit in a network.

This chapter includes the following sections:

- [Section 3.1, *Introduction* on page 30](#)
- [Section 3.2, *Software Upgrade* on page 31](#)
- [Section 3.3, *Manual Antenna Pointing \(without OpenAMIP\)* on page 31](#)
- [Section 3.4, *Cross-Polarization* on page 36](#)
- [Section 3.5, *Acquire the Network* on page 43](#)
- [Section 3.6, *Set Power* on page 46](#)
- [Section 3.7, *16QAM Output Back-Off* on page 49](#)

3.1 Introduction

Commissioning is the process of preparing a terminal to be able to properly transmit in a network.



NOTE: For commissioning a remote with manual antenna, see [Manual Antenna Pointing \(without OpenAMIP\) on page 31](#). For commissioning a remote with automatic antennas, see [Cross-Polarization on page 36](#).



NOTE: PWM is not supported for the iQ Series satellite routers.

To commission a remote using the Terminal WUI, click **Commissioning > Commissioning Wizard**. See [Figure 3-1](#).




Figure 3-1. Commissioning Menu

Once the user clicks the Commissioning Wizard, the commissioning procedure starts with the following page:



Figure 3-2. Commissioning Wizard

3.2 Software Upgrade

See [Administration - Software & Configuration on page 23](#) and [Loading Configuration Files using the Terminal WUI on page 24](#).

3.3 Manual Antenna Pointing (without OpenAMIP)

Follow the procedures in this section only if a remote is being commissioned with a manual antenna.

3.3.1 Selecting a Site

A comprehensive site survey is beyond the scope of this guide. However, keep the following general guidelines in mind when selecting the site:

- Select a level surface that is approximately 10 feet by 10 feet.
- Avoid proximity to other transmitters.
- Avoid exposing others to incident radiation.
- Verify a clear line-of-sight to the satellite.
- Consider availability of electrical power and routing of cables (power, IFL, LAN).
- Verify that the coaxial IF cables (Tx, Rx) can reach the Satellite Router from the selected antenna location. RG-6 cable may be used up to a distance of 250 feet. If the run is longer, RG-11 cable must be used up to a maximum distance of 500 feet.
- Ensure that cables do not cross roads or foot-traffic areas.

3.3.2 Assembly

Assemble the antenna and mount by following the manufacturer's assembly instructions. After installation, ensure that:

- The antenna base is fixed on a stable surface that will not shift.
- Ballast is installed on the antenna base (to combat wind).
- The mast pipe is plumb.

3.3.3 Orientation

The following section describes antenna orientation principles generally applicable to all site installations, illustrated with a typical VSAT antenna configuration. Magnetic variation and elevation offset principles are discussed in detail.



NOTE: The antenna may not be identical to the antenna used in this example. See the antenna manufacturer's instructions for specific information.

3.3.4 Magnetic Variation

Magnetic variation (also referred to as “declination”) is the difference between the true heading referenced to the geographic North Pole, and the magnetic heading as registered on a magnetic compass. The magnitude and direction of magnetic variation differs depending upon the geographic location. Magnetic variation changes slowly with time.

Figure 3-3 illustrates magnetic variation in the United States. More detailed, up-to-date maps are available on the Internet, and must be consulted for the latest data.




Figure 3-3. Example: Magnetic Declination

Magnetic variation alters the reading of a magnetic compass with respect to true North. Maps and map display systems, including the output of the iDirect **Look Angle Calculator**, are referenced to true geographic North. Therefore a correction factor must be applied to readings taken by a magnetic compass to obtain the correct value, referred to as the true heading.

Magnetic variation is specified in degrees East or West of the *agonic line* (line of zero variation), shown as a red dotted line in Figure 3-3. As depicted in the figure, East declination causes the compass to be deflected to the right of the true heading, while West declination causes the compass needle to deflect to the left of the true heading. Consequently, add West declination, and subtract East declination, from the compass reading to obtain the true heading.

For example, the illustration depicts the 10° West isogonic line passing through Baltimore, MD. In that location, 10 degrees must be added to the compass indication to obtain the true heading.

3.3.5 Sighting Antenna Azimuth

When sighting the antenna to determine azimuth, it is important to consider the effect of large metal objects nearby, which could influence the compass measurement.

Measure from behind the antenna, looking in the direction of the feed horn. Walk around behind the antenna and watch the compass to determine if the field is uniform or if anomalies exist.

Use an object in the far background as a target to align the compass. Sight along a line perpendicular to the plane of the reflector. The back plate of the reflector assembly can serve as a reference.

Add or subtract the declination in your location to the compass reading. This is the true heading of the antenna. When aligning the antenna to the value determined by the **Look Angle Calculator**, mark the position with a line drawn across the lower section of the azimuth mount and the pole using an indelible marker.

3.3.6 Elevation Offset

An offset antenna has the virtue of unobstructed antenna aperture, especially beneficial for VSAT terminals. Reflector optics are modified from a parabola, allowing the feed to be placed off the mechanical axis. The resulting beam (optical) axis is offset by an angle equal to the angle between the feed and the mechanical axis. See [Figure 3-4](#).

A typical 1.8 meter antenna has a 22.6° offset, while a typical 1.2 meter antenna has a 17° offset. For example, the antenna reflector elevation required to achieve a beam angle of 50° relative to the horizon is calculated as follows for a 1.8 meter antenna:

$$50^{\circ} - 22.6^{\circ} = 27.4^{\circ}$$

The reflector back plate is perpendicular to the mechanical axis of the antenna. When the back plate is vertical (90°), the beam elevation is 22.6°. To move the beam axis to the desired 50° elevation angle as in the example above, the antenna back plate is elevated from 90° to 117.4° (90 + 27.4) or, depending on the type of inclinometer used, a reading of 62.6° (90 - 27.4).

Always refer the original equipment manufacturer's (OEM) installation instructions when installing the antenna and mount. Consult the OEM specifications to determine the offset angle for the particular antenna being installed.




Figure 3-4. Antenna Elevation Offset

3.3.7 Using the Terminal WUI

On the terminal WUI, click **Commissioning > Commissioning Wizard**. On the **Coarse Antenna Pointing** page (Figure 3-5), read the values on the right-hand side of the page and use those values to physically point the antenna. Click **Save Remote Location and Continue**.

The screenshot shows the 'Commissioning Wizard' interface. At the top, a progress bar has 8 steps, with step 3, 'Coarse antenna pointing', highlighted. Below the progress bar, the title 'Coarse antenna pointing' is centered. A blue instruction box reads: 'Please adjust the values on the left in order to calculate the coarse antenna pointing on the right.' The interface is divided into four main sections:

- Remote Position:** Includes input fields for Remote Latitude (0.0000), Remote Latitude Direction (North), Remote Longitude (0.0000), and Remote Longitude Direction (East).
- Antenna:** Includes an input field for Elevation Offset (0.0000).
- Calculated coarse antenna pointing:** Displays calculated values: Elevation Actual (90.0 degrees (Actual = True - Offset)), Azimuth True (0.0 ° (Geographic north = 0°)), Polarization Offset (0.0 ° (Polarization Angle Sense)), and Elevation True (90.0 ° (Horizontal = 0° Straight up = +90°)).
- Satellite Position:** Includes input fields for Satellite Longitude (0.0000) and Satellite Longitude Direction (East).

A blue button at the bottom right is labeled 'Save remote location and continue'.

Figure 3-5. Antenna Pointing

On the **Configure Downstream** page (Figure 3-6), ensure the frequency and other parameters are correct. Click **Continue**. To change the frequency or any other parameter, click **Administration > Software and Configuration**.




Figure 3-6. Configure Downstream



NOTE: Before pointing the antenna to the satellite, ensure the highlighted step in the **Fine Antenna Pointing** page is followed. Always point the antenna to clear sky first and mark the measurement.

On the **Fine Antenna Pointing** page (Figure 3-7), physically position the antenna to point to the satellite.




Figure 3-7. Antenna Pointing

Point the antenna (satellite dish) towards the clear sky. Click **Start Antenna Pointing** to initialize the graphing of the received signal. Physically start rotating/moving the antenna towards the direction of the satellite (as calculated in the coarse pointing page). The graph starts to display an increase in received signal. Direct the antenna to the direction where the graph displays the highest voltage.

When the **Demod Lock Status** displays **Locked**, click **Continue**.

3.4 Cross-Polarization

This section describes how to minimize return link cross-pol energy under the guidance of the satellite access control center.

3.4.1 Overview

Cross-pol isolation is measured over-the-air by the satellite access control center. Be prepared to contact the Network Operator by telephone.

Transmit cross-pol isolation is maximized in order to limit interference to users on the opposite polarity of linearly-polarized satellite transponders. Typically, the spacecraft operator requires a minimum of 30 dB of isolation. To measure this, the terminal must transmit at a power level at least 30 dB above the noise floor of the transponder. The satellite access control center measures and compares the received co-pol and cross-pol energy to determine if the site meets polarity isolation standards.

VSAT terminals using circularly-polarized feed systems need not perform cross-pol tests.

To Prepare for Cross-Pol Adjustment:

1. Disconnect power from the Satellite Router.
2. Disconnect the receive IF cable from the Satellite Router.
3. Connect the transmit IF cable to the BUC Tx input.
4. Connect power to the Satellite Router.
5. Connect to the satellite router's web user interface using a Web browser.
6. Log in as **Admin** and click **Commissioning > Cross Polarization/P1dB**. See [Figure 3-8](#).




Figure 3-8. Terminal WUI Cross Polarization Page

3.4.2 Satellite Access



WARNING: Do not click the **Turn on Signal** until instructed to do so by the satellite access control center. Clicking the **Turn on Signal** causes the Satellite Router to transmit a continuous-wave (CW) signal to the satellite.

While still connected to the Satellite Router, call the Network Operator. The Network Operator will establish a conference call with the satellite access control center. The access controller will assign an uplink frequency for performing the cross-pol isolation adjustment. For a Satellite Router that transmits an SCPC return channel, the assigned test frequency may be the same as the final operating frequency. For TDMA terminals, cross-pol must be measured at a test frequency different from the traffic-carrying channel.

Preparation

Follow the steps below to prepare for satellite access and cross-pol adjustment:

To Prepare for Satellite Access:

1. Loosen the fasteners securing the feed, as well as the hose clamp on the BUC, so that the entire assembly (feed, BUC, and LNB) rotates freely.
2. Provide the final antenna pointing voltage reading to the Network Operator. The Network Operator records the value.
3. Obtain the test frequency from the satellite access controller.

4. Under **Commissioning > Cross Polarization/P1dB**, under **RF Uplink Frequency** ([Figure 3-8](#)) enter the test frequency.



NOTE: The BUC LO Frequency is read from the options file loaded on the Satellite Router. Using the RF Uplink Frequency and BUC LO Frequency, the L-band TX Frequency is calculated automatically.

5. Verify with the Network Operator that the displayed **L-band TX Frequency** is correct.
6. In **Adjust Transmit Power**, set power to **-35 dBm**.

3.4.3 Performing Cross-Pol Adjustment

During adjustment of the antenna feed, the satellite access controller observes the transmitted signal on a spectrum analyzer, switching from co-pol to cross-pol to compare levels. The controller will ask for power to be increased until sufficient energy is available to detect the cross-pol signal. At that time a polarity adjustment is made. The controller may ask for more changes in transmit power and additional polarity adjustments as needed until the required level of isolation is achieved.

The access controller will not specify a transmit power in absolute terms, such as -35 dBm or -20 dBm. Instead, the controller will ask for power increases or decreases in relative terms, such as a 1 dB increase, or a 2 dB decrease. Perform the following procedure when instructed by the access controller.

To Start the CW Carrier and Adjust TX Polarity Isolation:

1. On the Terminal WUI, click **Turn On Signal** ([Figure 3-8](#)).
2. In the terminal WUI, adjust the transmit power as instructed by the access controller by selecting the appropriate power value in the **Transmit Power** section of the Cross Polarization screen. (See [Figure 3-8](#))
3. At the instruction of the access controller, rotate the feed slowly in one direction. Move the assembly in small ($1/2^\circ$) increments.
4. Wait for the access controller to make a measurement. The access controller may say to continue moving the feed in the same direction, or to reverse direction. Continue as directed until the required isolation is achieved.
5. Secure all fasteners and the hose clamp.

It may be necessary to re-peak azimuth and elevation in order to achieve sufficient cross-pol isolation. The access controller may ask for fine adjustments in azimuth or elevation before repeating the cross-pol adjustment. Follow the directions of the access controller. Securely fasten all antenna axes after peaking and isolation have been optimized.

3.4.4 After Securing the Antenna

Wait for the access controller to verify that cross-pol isolation and peaking did not change due to tightening of the antenna axis fixing hardware. Confirm that the Network Operator has recorded the final cross-pol isolation value.

When directed to modulate the test carrier, perform the following:

1. Using the Terminal WUI, on the **Cross Polarization/P1dB** page (see [Figure 3-8](#)):
 - a. In the **Modulation** field of the **Modulator** section, select **BPSK**.
 - b. Enter the **Symbol Rate** as directed.
 - c. Click **Turn On Signal**.

3.4.5 Establish 1dB Compression Point and Maximum Power

This section describes how to determine the IF drive level that causes 1dB gain compression of the Block Up-Converter (BUC). This IF level is the “never exceed” level for driving the particular BUC used.

Preparation

Determination of the 1dB compression point (P1dB) is made immediately following successful cross-pol adjustment. The Satellite Router is transmitting a high-level continuous-wave (CW) signal to the satellite, and the respective **Cross Polarization** windows are open on the local PC user interface. Under direction of the satellite access control center, the Satellite Router transmit IF level is increased until BUC gain compression is detected.

To determine the 1dB compression point, the access controller must carefully measure incremental power changes at a high resolution. It may be necessary to perform the procedure more than once to be certain that the 1dB compression point is properly identified. Follow the direction of the access controller.

The 1dB compression point is defined as the output power level at which BUC amplifier gain has decreased by 1dB from the small-signal value. If, for example, a particular amplifier exhibits a low-power gain of 40dB, the P1dB point is the output power level at which gain has been reduced to 39dB. See [Figure 3-9](#) for an illustration of the concept using sample data representing a typical solid-state amplifier.

Although the P1dB point is located beyond the start of gain compression and is therefore in the non-linear region of the transfer characteristic, most BUCs can operate safely at that power level without exceeding the limits imposed by the transmit spectral mask. Many current BUCs are able to maintain acceptable Adjacent Channel Power Ratios (ACPR) while operating within a dB or less of maximum rated power.

Network designers consult manufacturer data sheets to determine the operating point and headroom requirements of individual amplifiers. The considerations are incorporated into link budget and site provisioning calculations. The purpose of P1dB determination in the iDirect system is to set a maximum IF transmit power limit for each site.

Pin	Pout	Pout Increase	Delta	Gain
-14	26	1	0	40
-13	27	1	0	40
-12	28	1	0	40
-11	29	1	0	40
-10	30	1	0	40
-9	31	1	0	40
-8	32	1	0	40
-7	32.9	0.9	0.1	39.9
-6	33.7	0.8	0.2	39.7
-5	34.4	0.7	0.3	39.4
-4	35	0.6	0.4	39
Sum of deltas = 1				
-3	35.5	0.5	0.5	38.5
-2	35.9	0.4	0.6	37.9
-1	36.2	0.3	0.7	37.2
0	36.4	0.2	0.8	36.4
1	36.5	0.1	0.9	35.5
2	36.5	0	1	34.5
3	36.5	0	1	33.5

Linear Region




Figure 3-9. Sample Transfer Characteristic

Determine 1dB Compression Point

Perform the 1dB Compression Point test using the same CW carrier used during the cross polarization test. This test determines the point at which Satellite Router transmit power, saturates the BUC.

Using Terminal WUI to perform this procedure in the **Transmit Power** section of the Cross Polarization page, see [Figure 3-10](#).




Figure 3-10. Adjust Transmit Power



WARNING: To avoid over driving the satellite, the BUC and antenna must be sized correctly for the network.

To determine the 1dB Compression Point, perform the following:

1. With the access controller observing the transmitted CW signal, increase the **Transmit Power** in Terminal WUI by 1dBm.



WARNING: If no power increase is observed, the BUC be saturated; this is unusual, *but* it can occur. Reduce power and re-attempt.

2. If a 1dB increase in power is observed, increase the **Transmit Power** by another 1dBm.
3. Repeat [Step 2](#) until the observed power increase is less than 1dB.
4. Subtract the observed power increase from 1. For example, if power increased by 0.8dB, the difference is 0.2dB. Record the difference as “delta.”
5. Increase the **Transmit Power** by 1dBm. Confirm that the observed power increase is again less than 1dB from the previous value. Add the difference from 1 to the delta recorded in [Step 4](#).
6. Repeat [Step 5](#) until the sum of all differences (delta) is equal to 1.
7. Record the **Transmit Power** setting of the Satellite Router at the point at which delta equals 1. This is the 1dB compression point. The Network Operator will enter this value later as the Maximum Power for the remote site in iBuilder.

- Click the **Stop** button in iSite or Web iSite to turn off the CW carrier.



NOTE: Do not restart or remove power from the Satellite Router.

The 1dB compression point has now been established, please proceed to [Acquire the Network](#) on page 43.

3.4.6 Using the Terminal WUI

On the Terminal WUI, click **Commissioning > Commissioning Wizard**. On the **Cross Polarization test** page (see [Figure 3-11](#)), under **CW Transmit Frequency**, enter the **RF Uplink Frequency**. The **BUC LO** and **L-Band Tx Frequency** are automatically displayed.

Figure 3-11. Cross Polarization test



NOTE: The satellite provider should provide the RF Uplink Frequency and the NOC operator should provide the Adjust L-Band Transmit Power.

Under **Transmit Power**, select the **Adjust L-Band Transmit Power** from the drop-down box.

Click **Turn on Signal** once the RF Uplink Frequency and Adjust L-Band Transmit Power are entered. The router starts transmitting CW (continuous waves) at the specified frequency and transmit power.

The user can increase or decrease the frequency and transmit power. Once the CW is transmitted accurately at the desired level, click **Turn off signal and Complete** to stop transmitting CW.

Click **Continue**. The **Exit Commissioning Mode** page is displayed.




Figure 3-12. Exit Commissioning Mode

Click **Exit Commissioning Mode** to complete commissioning the terminal.




Figure 3-13. Commissioning Complete

3.5 Acquire the Network

This section describes initial acquisition of the Satellite Router into the network.

3.5.1 Overview

After executing a restart, the Satellite Router performs a power-on self-test (POST) and acquires the network. Restarting causes the Satellite Router to conform to the operational state defined in the options file, including transmit frequency and initial power settings.

Upon completion of POST, the Satellite Router tunes to and locks on the downstream carrier, which contains an invitation to join the network in the form of acquisition slot assignments on the upstream carriers. The Satellite Router transmits one or more acquisition bursts to facilitate synchronization and allow the Satellite Router to join the network and begin transmitting traffic bursts.

The first acquisition bursts from a newly-commissioned site are transmitted at the power level specified in the options file. This “first burst” power level is determined by the Network Operator when configuring the site in iBuilder.

The initial acquisition or “first burst” power may or may not be sufficient for reliable acquisition. iDirect recommends that the initial power in the commissioning options file be set at a low value (for example, -35dBm) to ensure that the satellite router does not cause interference on the transponder when transmitting its first acquisition bursts.

After the Satellite Router has been acquired into the network for the first time, the Network Operator must set two power parameters in iBuilder: the maximum site power, and the power to be used for future acquisition bursts, referred to as the initial transmit power. The procedures for setting these parameters are contained in [Set Power on page 47](#).



NOTE: The initial transmit power must be determined under clear sky conditions.

3.5.2 Initial Acquisition

Following establishment of the P1dB Compression point, the Satellite Router is powered on and the receive IF cable is disconnected. Perform the following procedures under clear sky conditions to acquire the network for the first time.



NOTE: In a TRANSEC network, the network operator must disable authentication for the Satellite Router on the iBuilder Remote Information tab and apply a hub-side configuration. See “Using the iDirect CA Foundry” in the iBuilder User Guide.

To Prepare to Acquire the Network:

1. Remove power from the Satellite Router.
2. Reconnect the receive IF cable from the LNB to the **RX In** port.
3. Reconnect power to the Satellite Router.
4. Monitor the Satellite Router LEDs to observe progress and confirm the Satellite Router receiver has locked to the outbound carrier.

Depending on the initial power setting in the options file, the Satellite Router may or may not join the network. In either case, the Network Operator should complete the following steps to bring the Satellite Router into the network (if necessary) and to determine the clear sky operating power of Satellite Router. During this procedure, the local installer should monitor the Satellite Router acquisition status as the Network Operator adjusts power.

To Acquire the Network and Determine the Clear Sky Transmit Power:

1. Log in to iMonitor.
2. In the iMonitor Tree, expand the Inroute Group containing this Satellite Router.
3. Right-click the Satellite Router in the iMonitor Tree and select **Probe** from the menu.

4. In the **Remote Power** section of the **Probe** dialog box, click **Change** to open the **Change Remote Tx Power** dialog box (Figure 3-14).




Figure 3-14. iMonitor Probe: Changing the Satellite Router Transmit Power



NOTE: For TDMA remotes, the Transmit Power displayed in the Remote Power section of the Probe represents the Satellite Router transmit power relative to the reference carrier when the remote is in the network. This value is unknown until the Satellite Router joins the network and sends status to the NMS.

5. Ask the local installer to monitor the Satellite Router front-panel LED or Terminal WUI status indicators to determine when the remote has joined the network.
6. In the **Change Remote Tx Power** dialog box (Figure 3-14 on page 45):
 - a. In **Set New Tx Power**, enter the minimum transmit power for the Satellite Router, or enter a value several dBm below the value specified in the network link budget for this Satellite Router.



NOTE: The minimum transmit power of most Satellite Routers is -35dBm. The minimum transmit power of an X1 Satellite Router is -30dBm.

- b. Click **Set**.
- c. Slowly increase the transmit power by increments of 1dB and click **Set** until the remote joins the network.



NOTE: When the Satellite Router joins the network, the Transmit Power in the Remote Power section of the Probe will begin to update. However, there may be a delay of several seconds before the value is reported to the NMS. The Satellite Router LEDs provide a more timely indication of when the remote has acquired.

7. Wait for the **Transmit Power** displayed on the Probe to settle on a constant value and note the value. This value is required to set the correct Initial Power in iBuilder in [Set Power on page 47](#).

3.6 Set Power

This section describes how to set initial acquisition power and maximum transmit power for the remote site in iBuilder. The instructions provided in this section are performed by the Network Operator.

3.6.1 Overview

Remote site transmit power is controlled by the hub Protocol Processor Uplink Control Process (UCP). A UCP operates in a manner similar to other uplink power control systems, where received signal strength is compared to a nominal value, and adjustments are made based on the comparison. The UCP constantly measures performance and adjusts power as needed. See the *iDirect Technical Reference Guide* for details.

The power of acquisition bursts transmitted by the Satellite Router must be set as a constant since during acquisition the Satellite Router is not yet participating in the UCP loop. An acquisition or “initial” power must be configured that guarantees acquisition without overpowering the transponder or the receiver. iDirect defines initial power as the acquisition burst power. Initial power varies from site to site.

A separate quantity, referred to as maximum power, is the “never exceed” IF output power for the site. Maximum transmit power also varies from site to site. UCP enforces this limit, and uses the configured value to determine the available power headroom at each site.

After the 1dB compression point is determined, the Network Operator enters the initial and maximum power settings for the remote site in iBuilder. Immediately afterward, the Network Operator generates a new options file containing the updated information and sends it to the Satellite Router over the air.

The Reference Carrier

In an Adaptive TDMA network, the upstream transmission can change frequency, MODCOD, symbol rate and/or spreading factor at any time depending upon network demand, rain fade, or other rules. To provide a constant baseline for comparison, a reference carrier is defined for each remote site by the Network Operator. Reference carrier properties are set by the Network Operator on the Remote Information tab in iBuilder. For TDMA remotes, the initial transmit power is configured in relation to the Reference Carrier.

After the Satellite Router is acquired for the first time and the UCP process is operating, the Network Operator records the reference carrier power level as a clear-sky benchmark for the remote site. The **Transmit Power Relative to the Reference Carrier** is the Satellite Router IF output power that would be used if the remote site were to close the link at the required C/N_0 using a carrier with properties identical to those defined for the reference carrier.

The **Transmit Power Relative to the Reference Carrier** is displayed on the iMonitor Probe screen. The Network Operator notes the transmit power level after acquisition and uses it as the starting point for determining the initial power setting in iBuilder.

The procedure to bring the remote into the network for the first time and determine the transmit power level is [Initial Acquisition on page 44](#).

[Figure 3-15](#) shows the related sections of the iMonitor Probe (left) and the iBuilder Remote Information tab (right) after commissioning. In the figure, the Satellite Router is in the network and is currently transmitting (under UCP control) at -21.78dBm relative to the

configured reference carrier. The Satellite Router sends acquisition bursts at -20dBm when trying to acquire on a carrier that matches the reference carrier. When acquiring on a carrier with a different configuration, the Satellite Router automatically adjusts the transmit power of the acquisition burst such that it is received by the hub at the correct C/N_0 .




Figure 3-15. Initial Power in Probe and iBuilder



NOTE: For more information on configuring the reference carrier, refer to the *iBuilder User Guide* and the *Technical Reference Guide*.

Maximum Power

For each remote site, there is an absolute upper power limit imposed by the limitations of the RF amplifier or BUC. For each BUC, there is also an upper limit of *usable* power imposed by the linearity characteristics of the amplifier itself, in conjunction with the minimum spectral purity requirements for the output signal.

Setting the maximum power in iBuilder has two purposes:

1. To ensure the remote site BUC is not driven so far into the non-linear region that unacceptable levels of spectral regrowth occur; and
2. To establish a reference point for the Uplink Control Process to determine the usable power headroom available at the remote site at any given time.

The data needed to set maximum power on the iBuilder Remote Information tab was obtained during the procedure executed in [Determine 1dB Compression Point on page 41](#).

3.6.2 Set Power

After completing the steps in [Acquire the Network on page 43](#), the Satellite Router is acquired into the network and the Protocol Processor UCP loop is controlling power.

Setting TDMA Initial Power and Maximum Power

Use the following procedure to set initial and maximum power for TDMA remote sites.



WARNING: Setting initial power too high above normal operating levels can cause problems with remote acquisition into the network or interfere with network operation.

To Set Initial and Maximum Power (TDMA):

1. Log in to iBuilder.
2. Right-click the remote in the iBuilder Tree and select **Modify > Item** to open the Remote Information tab.
3. Scroll down to the **Reference Carrier** section (Figure 3-16).

The screenshot shows the 'Reference Carrier' tab of the 'iBuilder Transmit Properties' dialog. The 'TDMA Initial Power' field is highlighted in yellow and set to -31. Other fields include Symbol Rate (5000 ksym), Chip Rate (5000 kchip), MODCOD (QPSK3/4), Spreading Factor (No Spreading), Payload (170), TDMA Max Power (0 dBm), and 1 dB Compression Point (0). There is a 'Details...' button at the bottom right.

Figure 3-16. iBuilder Transmit Properties: TDMA

4. Set **TDMA Initial Power** to the **Transmit Power** recorded in [Step 7 of Initial Acquisition on page 44](#) plus any link budget margin required to acquire the network under all conditions.
5. Set **TDMA Max Power** to the (CW) P1dB point determined in [Determine 1dB Compression Point on page 41](#).
6. Enter the same value in the **1dB Compression Point** field. (This is an optional field for information only).
7. Click **OK** to save the changes.
8. Right-click the remote in the iBuilder Tree and select **Apply Configuration > Reliable Both (TCP)**.

If commissioning a remote in a TRANSEC network AND authentication is disabled, perform the following steps:

1. If the remote is *not* yet issued an X.509 certificate, issue the certificate now. (See the *iBuilder User Guide* appendix “Using the iDirect CA Foundry” for details.)
2. Re-enable authentication on the remote Information tab by clearing the **Disable Authentication** check box.
3. Click **OK** to save the changes.
4. Right-click the remote in the iBuilder Tree and select **Apply Configuration > Reliable Both (TCP)**.

3.7 16QAM Output Back-Off

Starting with iDX Release 4.1.3, 16QAM modulation is supported for the iQ Series satellite routers.

As a result of the higher linearity requirement for 16QAM, power amplifiers need to be backed off from their normal max output power which is set through the 1dB compression procedure during terminal commissioning, [Determine 1dB Compression Point on page 41](#). The optimal amount of output back off (OBO) is to be determined immediately after terminal commissioning.

To set OBO on a remote for 16QAM transmission, perform the following:

1. On iBuilder client, set the OBO value for the remote to 1dB before generating the options file for commissioning.

The screenshot shows the 'Modify Configuration Object' window for an IQ200RM 59445 satellite router. The 'Reference Carrier' tab is selected, showing the following settings:

- Symbol Rate: 15000 ksym
- Chip Rate: 15000 kchip
- MODCOD: 16QAM6/7
- TDMA Initial Power: -16.5
- Spreading Factor: No Spreading
- Payload: 438
- Lock to Inroute: [unchecked]
- TDMA Max Power: 0 dBm
- 1 dB Compression: 0
- OBO: 1 dB** (highlighted with a red box)

A red warning message is displayed: "Warning: custom parameters are in effect for this remote!". Other tabs include Information, QoS, Layer 2, Layer 3, Ports, Geo Location, VSAT, Warning Properties, License Properties, and Pool License. The 'Remote' section on the left includes fields for Name, Model Type, Serial Number, Derived ID, Inroute Group, User Password, and Admin Password. The 'Receive Properties' section on the right shows Carrier Name, L-Band, and Fan Out Translation settings.

Figure 3-17. Setting Up OBO Value Before Commissioning

2. Commission the terminal using the procedures described in this chapter including the setting of Pmax using 1dB compression procedure and the initial Tx power.

3. Determining the optimal OBO requires that the terminal is in an inroute group that has 16QAM carriers and has the link budget to support these carriers. If not, the subsequent steps should be postponed till these conditions are met.
4. Under clear sky condition for the terminal, after the remote is acquired into the network, observe the following:
 - a. Is this terminal CRC-free?

Using iMonitor client, monitor the CRCs on the terminal and on the line card configured with 16QAM carrier.




Figure 3-18. CRC Monitoring on iMonitor

- b. Is the terminal able to reach the inroute carriers for which the link budget was designed?

Verify if C/N0 reported by the terminal meets requirement for 16QAM.

Time	Up C/No [dBHz]	Power Adjustm...	Timing Offset [...]	Freq Offset [Hz]
5/15/2019 1:21:06 PM	84.59	0.0	-58	-8658
5/15/2019 1:21:11 PM	84.58	0.0	-58	-8761
5/15/2019 1:21:16 PM	84.58	0.0	-58	-8503
5/15/2019 1:21:21 PM	84.59	0.0	-58	-8768
5/15/2019 1:21:26 PM	84.59	0.0	-58	-8800
5/15/2019 1:21:31 PM	84.58	0.0	-59	-8693
5/15/2019 1:21:36 PM	84.58	0.0	-56	-8610
5/15/2019 1:21:41 PM	84.59	0.0	-56	-8618
5/15/2019 1:21:46 PM	84.59	0.0	-57	-8590
5/15/2019 1:21:51 PM	84.58	0.0	-57	-8712
5/15/2019 1:21:56 PM	84.58	0.0	-57	-8560
5/15/2019 1:22:01 PM	84.59	0.0	-57	-8720
5/15/2019 1:22:06 PM	84.59	0.0	-57	-8702
5/15/2019 1:22:11 PM	84.58	0.0	-57	-8520
5/15/2019 1:22:16 PM	84.58	0.0	-58	-8694
5/15/2019 1:22:21 PM	84.59	0.0	-58	-8709
5/15/2019 1:22:26 PM	84.59	0.0	-56	-8610
5/15/2019 1:22:31 PM	84.59	0.0	-56	-8814

Figure 3-19. C/N0 verification for 16QAM requirement

5. If the answer is “No” to any question above, then try increasing OBO in 0.5dB step and redo step 4.

Appendix A Acronyms and Abbreviations

The list in this appendix is meant to be generic and may contain acronyms and abbreviations not found in this manual and some terms may not be defined based on industry standards of knowledge.

0...9

16APSK	Sixteen Amplitude and Phase Shift Keying
16QAM	A quadrature amplitude modulation
8PSK	Eight Phase Shift Keying

A

A-TDMA	Adaptive Time Division Multiple Access
ABS	Automatic Beam Switching
AC	Alternating Current
ACM	Adaptive Coding and Modulation
ACS	Antenna Control System
AES	Advanced Encryption Standard
APSK	Amplitude and Phase-shift keying
AWG	American Wire Gauge
AZ	Azimuth

B

BB	BaseBand
BIM	Below-Decks Interface Module
BIST	Built-In Self-Test
BITE	Built-In Test Equipment
BPN	BUC Part Number
BPSK	Binary Phase Shift Keying

BSN	BUC Serial Number	EL	Elevation
BTP	Burst Time Plan	EMC	ElectroMagnetic Compatibility
BUC	Block Up Converter	EMI	ElectroMagnetic Interference
		ETSI	European Telecommunications Standards Institute
C			
C/N	Carrier to Noise ratio		
C/N0	Carrier C/N threshold	F	
CBIT	Continuous Built In Test	FCC	Federal Communication Commission
CDR	Critical Design Review	FEC	Forward Error Correction
CIR	Committed Information Rate	FID	Functional ID
CPE	Customer Premise Equipment	FMECA	Failure Mode Effects Criticality Analysis
CPU	Central Processing Unit	FPGA	Field Programmable Gate Array
CRC	Cyclic Redundancy Check	FS	Functional Specification
CSA	Canadian Space Agency		
		G	
D		G/T	Gain over Temperature
DAC	Digital to Analog Converter	GHz	GigaHertz
dB	deciBel	GPIO	General-Purpose Input/Output
dB _i	deciBel isotropic	GPS	Global Positioning System
dB _m	deciBel milli-Watt		
dBW	deciBel Watt	H	
DC	Direct Current	HCP	High-Capacity Payload
DDR	Double Data Rate		
DHCP	Dynamic Host Configuration Protocol	I	
DNS	Domain Name Service	IBIT	Initiated Built In Test
	DVB-S2	ICD	Interface Control Document
	Digital Video Broadcasting over Satellite, Second Generation	ICMP	Internet Control Message Protocol
		iDX	Evolution Software System
E		IEC	International Electrotechnical Commission
EIRP	Effective Isotropic Radiated Power	IFL	Inter-Facility Link
Eb/N0	Bit Energy to Noise Power Spectral Density ratio	IF	Intermediate-frequency
EEPROM	Electrically Erasable Programmable Read-Only Memory	IP	Ingress Protection
		IP	Internet Protocol

IR	Information Rate	NF	Noise Figure
		NOR	Not OR
J		NMS	Network Management System
K		O	
kbps	kilobit per second	OAE	Outside Antenna Equipment
kHz	kilohertz	ODU	Outdoor Unit
KRFU	Ku/Ka-band Radio Frequency Unit	OEM	Original Equipment Manufacturer
ksps	kilosymbol per second	OMT	Orthogonal-Mode Transducer
		OpenAMIP	Open Antenna-Modem Interface Protocol
L		OTA	Over The Air
LAN	Local Area Network	OTP	One Time Programmable
LDPC	Low-Density Parity Coding		
LED	Light Emitting Diode	P	
LNB	Low Noise Block Converter	PA	Power Amplifier
LOS	Loss of Signal	PAST	Person-Activated Self-Test
LRU	Line-Replaceable Unit	PCB	Printed Circuit Board
M		PC	Personal Computer
Mbps	Megabits per second	PDR	Preliminary Design Review
Mcps	Megachips per second	PLL	Phased Locked Loop
MES	Mobile Earth Station	PSK	Phase Shift Keying
MF-TDMA	Multi-Frequency TDMA	PSU	Power Supply Unit
MHz	Megahertz	PWM	Pulse width modulation
MID	Manufacturer ID	Q	
MIL-STD	US Military Standard	QEF	Quasi Error Free
MODCOD	Modulation and Coding	QoS	Quality of Service
Msp	Mega Symbols per Second	QPSK	Quadrature Phase Shift Keying
MTBF	Mean Time Between Failures	R	
MTBUR	Mean Time Between Unscheduled Removals	RF	Radio Frequency
N		RGMI	Reduced Gigabit Media Independent Interface
NAND	Not AND	RMS	Root Mean Square
		RoHS	Restriction of Hazardous Substances

ROM	Read-Only Memory	VDC	Volts Direct Current
RSSI	Receive Signal Strength Indication	VSAT	Very Small Aperture Terminal
RTP	Real-Time Protocol		
Rx or RX	Receive	W	
S		WFQ	Weighted Fair Queuing
SAS	Satellite Access Station	WGS	Wideband Global SATCOM
SCPC	Single Channel Per Carrier	X	
SGMII	Serial Gigabit Media Independent Interface	X	
SIM	Subscriber Identity Module		
SNR	Signal to Noise Ratio	Z	
SRS	Systems Requirement Specification		
SRU	Shop Replaceable Unit		
SSB	Single Side Band		
T			
TBD	To Be Defined		
TCP	Transmission Control Protocol		
TDMA	Time Division Multiple Access		
TFI	Terminal Functional ID		
TMI	Terminal Manufacturer ID		
TPCFEC	Turbo Product Code FEC		
TPN	Terminal Part Number		
TSN	Terminal Serial Number		
TTC	Terminal Transmit Control		
Tx or TX	Transmit		
U			
UDP	Universal Data Protocol		
UL	Underwriters Laboratories		
V			
VAC	Volts Alternating Current		

Appendix B Remote Locking

Soft, temporary, and hard locking for an iQ Series or 3315 Series remote requires a unique Locking Key for each satellite router which is formed using a combination of the Network Key and a randomly generated Confirmation Word to securely lock satellite routers to a network.

An iQ Series or 3315 Series remote can be configured with a hard (permanent) lock. However, during the configuration of a hard lock, the network operator may choose to create a temporary lock. This is to allow a network operator to test the lock for the first iQ Series or 3315 Series remote in order to verify operation, and to record the Netkey Fingerprint that is returned.

A hard locked satellite router cannot be unlocked; it must be returned to iDirect for a Non-Warranty RMA hardware replacement. A Netkey Fingerprint can help to avoid errors when locking the satellite router. The fingerprint identifies the network for the satellite router without revealing the Network Key on the satellite router.

A remote locked with a Soft Lock can be unlocked by entering the Confirmation Word provided when the lock was performed. If the Confirmation Word is lost, the soft lock cannot be disengaged. In order to unlock the remote, it must be returned to iDirect for a Non-Warranty RMA hardware replacement.

Remote locking is performed at the operator's own risk. Non-Warranty RMA charges (plus all shipping) apply to all satellite routers returned to iDirect for the purpose of removing a network lock.



WARNING: It is possible to remove a soft lock or temporary lock using the Terminal WUI. However, it is not possible to remove a hard lock using the Terminal WUI. Removing a hard lock requires returning the satellite router to iDirect for a Non-Warranty RMA hardware replacement.



NOTE: Non-Warranty RMA and shipping charges apply to all satellite routers returned to iDirect for the purpose of removing a network lock.

This appendix contains the following sections:

- [Locking the Remote on page 58](#)
- [Configuring the Network Key on page 58](#)
- [Performing a Temporary Lock on page 62](#)
- [Performing a Soft Lock on page 63](#)
- [Performing a Hard Lock on page 64](#)

- [Unlocking a Soft Lock on page 65](#)

B.1 Locking the Remote

Temporary, Soft, and/or Hard locking an iQ Series or 3315 Series remote requires the following:

1. Creating the Network Key at the network level in iBuilder, and applying the changes. See [Configuring the Network Key on page 58](#).
2. Connecting to the satellite router to be locked and entering the Network Key.
3. Generating the **Netkey Fingerprint** and **Confirmation Word**, and recording their values.
4. Locking the remote.

B.2 Configuring the Network Key

Remote Locking of any sort requires the creation of a Network Key before locking the satellite routers to a network. Create the Network Key by configuring the following custom key on the Custom tab for the network in iBuilder:

```
[NETWORK_DEFINITION]
net_key = <Network Key>
```

where <Network Key> is a string of between 5 and 64 alphanumeric characters.

After configuring the custom key in iBuilder, propagate the key to all satellite routers in the network by applying the changes to the network.

During operation, if a locked satellite router receives a Network Key message containing a Network Key that is different from the key set on the satellite router, the satellite router immediately stops sending upstream messages.

B.3 The Remote Lock Process

This section contains figures that show the Remote Lock process. These figures are referenced in the following sections:

- [Performing a Temporary Lock on page 62](#)
- [Performing a Soft Lock on page 63](#)
- [Performing a Hard Lock on page 64](#)
- [Unlocking a Soft Lock on page 65](#)




Figure B-1. Login Page Showing Username as "developer"




Figure B-2. Lock Type Drop-Down List Options




Figure B-3. Netkey, Fingerprint, and Confirmation Word




Figure B-4. Warning at Page Bottom




Figure B-5. Confirm Netlock Pop-Up Window




Figure B-6. Final Lock Status

B.4 Performing a Temporary Lock

Performing an optional Temporary Lock allows a network operator to test the locking of the first iQ Series or 3315 Series remote, to verify operation, and to record the Netkey Fingerprint that is returned. Perform the following steps to temporarily lock the first iQ Series or 3315 Series remote in a network.

1. Using a Web browser, connect to the satellite router to be locked and log on as *developer*. See [Figure B-1](#).



NOTE: Locking a satellite router requires a developer login.

2. In the browser address bar, type `/#admin-netlock` to the right of the IP address. For example:

<https://192.168.0.1/#admin-netlock>



NOTE: If the satellite router is locked, only the **Lock Status** section of the page appears.

3. In the **Lock Status** section, verify **State** displays **Unlocked**.
4. In the **Lock Remote** section, select **temporary** from the **Lock Type** drop-down list. See [Figure B-2](#).
5. In the **Netkey** field, enter the Network Key obtained in section [Configuring the Network Key on page 58](#).
6. Click **Lock**. The **Lock Remote** section expands to show the following fields (see [Figure B-3](#)):
 - **Netkey**
 - **Netkey Fingerprint**
 - **Confirmation Word**



NOTE: When locking the satellite router, use the Netkey Fingerprint to catch typographical errors and prevent accidentally locking the satellite router to the wrong network. Record the Netkey Fingerprint value returned when locking the first satellite router to a network. When locking subsequent satellite routers, verify that the Netkey Fingerprint has the same value before confirming the lock.

7. Perform the following actions:
 - a. Review the warning at the page bottom (see [Figure B-4](#)).
 - b. Verify the **Netkey**.
 - c. Record the value of the **Netkey Fingerprint**.
 - d. Record the **Confirmation Word** that appears.
8. Click **Confirm** (see [Figure B-5](#)). The **Lock Status** section displays the **State** of the Lock Status (see [Figure B-6](#)).

B.5 Performing a Soft Lock

Perform the following steps to soft lock the first iQ Series or 3315 Series remote to a network.

1. Using a Web browser, connect to the satellite router to lock and log on as *developer*. See [Figure B-1](#).



NOTE: Locking a satellite router requires *developer* privileges.

2. In the browser address bar, type `/#admin-netlock` to the right of the IP address. For example:

<https://192.168.0.1/#admin-netlock>



NOTE: If the satellite router is locked, only the **Lock Status** section of the page appears.

3. In the **Lock Status** section, verify **State** displays **Unlocked**.
4. In the **Lock Remote** section, select **soft** from the **Lock type** drop-down list (see [Figure B-2](#)).
5. In the **Netkey** field, enter the Network key obtained in section [Configuring the Network Key on page 58](#).
6. Click **Lock**. The **Lock Remote** section expands to show the following fields (see [Figure B-3](#)):
 - **Netkey**
 - **Netkey Fingerprint**
 - **Confirmation Word**.



NOTE: When locking the satellite router, use the Network Key Fingerprint to catch typographical errors and prevent accidentally locking the satellite router to the wrong network. Record the Network Key Fingerprint value returned when locking the first satellite router to a network. When locking subsequent satellite routers, verify that the Network Key Fingerprint has the same value before confirming the lock.

7. Perform the following actions:
 - a. Review the warning at the page bottom (see [Figure B-4](#)).
 - b. Verify the **Netkey**.
 - c. Verify that the value of the **Netkey Fingerprint** matches the value recorded at Step 7 of [Performing a Temporary Lock on page 62](#).
 - d. Record the **Confirmation Word**.



WARNING: Recording the Confirmation Word is critical. Without the Confirmation Word, the unit will have to be returned to iDirect under Non-Warranty RMA repair.



NOTE: Each remote has a unique Confirmation Word. It may be necessary to maintain a table/database of each remote model, serial number, and Confirmation Word.

8. Click **Confirm** (see [Figure B-5](#)). The **Lock Status** section displays the **State** of the Lock Status (see [Figure B-6](#)).

B.6 Performing a Hard Lock

A hard lock permanently burns the Network Key into the remote hardware using the generated Confirmation Word.



WARNING: It is possible to remove a soft lock or temporary lock using the Terminal WUI. However, it is not possible to remove a hard lock using the Terminal WUI. Removing a hard lock requires returning the satellite router to iDirect for a Non-Warranty RMA hardware replacement.

To hard lock a remote into the network, do the following:

1. In a Web browser, connect to the satellite router to be locked and log on as *developer* at the Terminal WUI. See [Figure B-1](#).



NOTE: Locking a satellite router requires a developer login.

2. In the browser address bar, type `/#admin-netlock` to the right of the IP address. For example:

`https://192.168.0.1/#admin-netlock`



NOTE: If the satellite router is locked, only the **Lock Status** section of the page appears.

3. In the **Lock Status** section, verify **State** displays **Unlocked**.
4. In the **Remote Lock** section, select **hard** from the **Lock Type** drop-down list (see [Figure B-2](#)).
5. At the **Netkey** field, enter the Network Key obtained in [Configuring the Network Key on page 58](#).
6. Click **Lock**. The **Lock Remote** section expands to show the following fields (see [Figure B-3](#)):
 - **Netkey**
 - **Netkey Fingerprint**
 - **Confirmation Word**



NOTE: When locking the satellite router, use the Network Key Fingerprint to catch typographical errors and prevent accidentally locking the satellite router to the wrong network. Record the Network Key Fingerprint value returned when locking the first satellite router to a network. When locking subsequent satellite routers, verify that the Network Key Fingerprint has the same value before confirming the lock.

7. Perform the following actions:
 - a. Review the warning at the page bottom (see [Figure B-4](#)).
 - b. Verify the **Netkey**.
 - c. Verify that the value of the **Netkey Fingerprint** matches the value recorded at Step 7 of [Performing a Temporary Lock on page 62](#).



WARNING: The following step will permanently lock the satellite router to the network. Only a hardware replacement can reverse this lock.

8. Click **Confirm** (see [Figure B-5](#)). The **Lock Status** section displays the **State** of the Lock Status (see [Figure B-6](#)).



NOTE: Repeat these procedures to lock additional remotes.

B.7 Unlocking a Soft Lock

A remote locked with a Soft Lock can be unlocked by entering the **Confirmation Word** that was provided when the lock was performed. Perform the following steps to unlock a soft locked iQ Series or a 3315 Series remote:

1. Using a Web browser, connect to the satellite router to be locked and log on as *developer*. See [Figure B-1](#).



NOTE: Locking a satellite router requires a developer login.

2. In the browser address bar, type `/#admin-netlock` to the right of the IP address. For example:

<https://192.168.0.1/#admin-netlock>



NOTE: If the satellite router is locked, only the **Lock Status** section of the page appears.

The soft locked remote screen shown similar to [Figure B-6](#) appears.

3. Enter the **Confirmation Word** in the designated area (as noted during the locking of the remote) and press **Unlock**. See [Figure B-7](#).




Figure B-7. Soft Locked Screen

In the **Lock Status** section, the state displayed is **Unlocked**. See [Figure B-8](#).




Figure B-8. Unlocked State

B.8 Non-Warranty RMA Required to Remove Remote Locks

It is not possible to change or remove a hard lock or to open a soft lock without a Confirmation Word on an iQ Series or 3315 Series remote. In order to unlock the satellite router, return it to iDirect for a Non-Warranty RMA hardware replacement.



NOTE: RMA and shipping charges apply to all satellite routers returned to iDirect for the purpose of removing a network lock.





Appendix C Using the Unified Recovery Program (URP)

This appendix contains information about how to use the Unified Recovery Program (URP) to load a new software package on a SMB3315/MDM3315 satellite modems. It contains the following sections:

- [Section C.1, URP Overview on page 69](#)
- [Section C.2, Downloading a New Software Package on page 70](#)
- [Section C.3, Accessing the URP on page 70](#)
- [Section C.4, Installing Evolution Software on a Modem on page 71](#)



NOTE: URP is only supported on SMB3315 and MDM3315 satellite modems.

C.1 URP Overview

URP enables you to load a new software package on a satellite modem. The modem reboots with the new software image using the default options file, software, and passwords. Access to the Terminal WUI is available at 192.168.1.1.

URP use cases include:

- Loading a new software package on a failed modem.
- Recommissioning a modem into a new network.
- Recovering a modem that has been mis-configured.
- Booting a modem from a release in another partition.
- Configuring a modem for operation in at least two networks.

When a modem is booted to the partition specified by URP, contents of the directory `/sysopt/factory` are not modified if they are valid and contain the correct complement of files. Any missing directories associated with configuration files are reconstructed, as are missing or corrupt file system(s) for directories associated with configuration files. The contents of software loaded to other partitions are not modified.

If there are any questions regarding the instructions provided in this section, or additional information is needed, contact TAC at (703) 648-8151 or by e-mail at tac@idirect.net.

Evolution Software Installation Details

When the URP is used to install a Evolution software package on a modem, all of the existing Evolution configuration is cleared, including the following:

- `/sysopt/buc`
- `/sysopt/cache`
- `/sysopt/config/certs`
- `/sysopt/config/network`
- `/sysopt/config/sat_router`
- `/common/OTA_SatelliteBeamMap.json`

C.2 Downloading a New Software Package

To download the latest Evolution software release, perform the following:

1. Using your iDirect login name and password, log on to the iDirect TAC Web site (Service Now Customer Portal) at <https://support.idirect.net>.
2. Click **Software Downloads**.
3. In the **Product Line** section, click **Evolution**.
4. Download all applicable software packages.

C.3 Accessing the URP

1. Connect your laptop LAN port to the modem's local area network (LAN) Port 2 using an Ethernet cable, as described in [Terminal Web User Interface Login on page 2](#).
2. Hold down the reset button on the modem for ten seconds or longer, which will reboot the modem. Refer to the appropriate ST Engineering Installation Guide for the modem for information about the location of the reset button on your specific modem model and information about how to hold it down.
3. Wait for the modem to fully reboot.
4. Enter [192.168.1.1](#) in the address bar of a supported browser to connect to the URP user interface. The URP home page appears.




Figure C-1. URP Home Page

C.4 Installing Evolution Software on a Modem

1. From the URP home page, click **Install evolution**.




Figure C-2. URP Home Page - Install Evolution

2. Click **Choose File** and select the Evolution software package you wish to upload from your laptop.

Install evolution

Home Install Dialog Install Velocity Install Evolution Syslog

State

Install File Name: None - 0 bytes

Upload package

Choose File No file chosen

Begin Upload

Install to:

Release3:
Release4:

Reconfigure eMMC:

Yes:
No:

Begin Installation Reset Boot Release3 Boot Release4

Figure C-3. Choose the Evolution Software Package

3. Click **Begin Upload** to upload the selected Evolution software package from your laptop.

Home Install Dialog Install Velocity Install Evolution Syslog

State

Install File Name: None - 0 bytes

Upload package

Choose File v3315_MD...3.0.0-250.pkg

Begin Upload

Install to:

Release3:
Release4:

Reconfigure eMMC:

Yes:
No:

Begin Installation Reset Boot Release3 Boot Release4

Figure C-4. Upload the Evolution Software Package

4. Wait for the system to display that the upload is complete.



Figure C-5. Evolution Software Package Upload Complete

5. Click **Install Evolution** to return to the Evolution software installation page and confirm that the correct software package was uploaded.




Figure C-6. Evolution Software Package Upload Confirmation

6. Select to which partition on the modem you want to install the software package.

Home Install Dialog Install Velocity Install Evolution Syslog

State

Install File Name: /tmp/v3315_MDM3315_rootfs_ert_4.3.0.0-250.pkg - 82880753 bytes

Upload package

Choose File No file chosen

Begin Upload

Install to:

Release3:

Release4:

Reconfigure eMMC:

Yes:

No:

Begin Installation Reset Boot Release3 Boot Release4

Figure C-7. Select Modem Partition

7. Specify if you want to also reconfigure the embedded MultiMediaCard (eMMC). This option reconfigures the flash memory on the modem and is typically selected if your modem is in a failed state, if you wish to completely wipe the current software configuration from the modem or if you are switching from one software version to another (for example, from Dialog to Evolution).

Home Install Dialog Install Velocity Install Evolution Syslog

State

Install File Name: /tmp/v3315_MDM3315_rootfs_ert_4.3.0.0-250.pkg - 82880753 bytes

Upload package

Choose File No file chosen

Begin Upload

Install to:

Release3:

Release4:

Reconfigure eMMC:

Yes:

No:

Begin Installation Reset Boot Release3 Boot Release4

Figure C-8. Reconfigure the eMMC

- Click **Begin Installation** to install the software package on the modem.

Figure C-9. Evolution Software Package Installation

- The URP confirms that it has started to install the new software package on the modem.

Figure C-10. URP Started Installation Message

- Click **Syslog** to monitor the progress of the installation.

Syslog

[Home](#) [Install Dialog](#) [Install Velocity](#) [Install Evolution](#) [Syslog](#)

```

Jan 1 00:34:35 (none) user.notice root: Started Evolution Installation at Thu Jan 1 00:34:35 UTC 1970
Jan 1 00:34:35 (none) user.notice root: Calculating Package SHA512
Jan 1 00:34:40 (none) user.notice root: PKG_FILE = /tmp/v3315_MDM3315_rootfs_ert_4.3.0.0-250.pkg
Jan 1 00:34:40 (none) user.notice root: PARTITION = 5
Jan 1 00:34:40 (none) user.notice root: RECONFIGURE = no
Jan 1 00:34:40 (none) user.notice root: QUIET = 1
Jan 1 00:34:40 (none) user.notice root: PKG_SHA =
0a5bd66081e52c52e21daclabdd720635c40663e2757d7747bf4f565a7a9dd6405ed20a53d3566a38f7ef7687712df29adf2d86a8ac
Jan 1 00:34:40 (none) user.notice root: Unpacking /tmp/v3315_MDM3315_rootfs_ert_4.3.0.0-250.pkg to /tmp/temp
Jan 1 00:34:40 (none) user.notice root: SavePackage: [68BF] postinstall.sh (579)...Saved.
Jan 1 00:34:40 (none) user.notice root: SavePackage: [2C46] version (28)...Saved.
Jan 1 00:34:40 (none) user.notice root: SavePackage: [4152] idirect-release (34)...Saved.
Jan 1 00:34:40 (none) user.notice root: SavePackage: [2FE2] boardModel.xlate (24)...Saved.
Jan 1 00:34:40 (none) user.notice root: SavePackage: [4C13] install_file_map (325)...Saved.
Jan 1 00:34:41 (none) user.notice root: SavePackage: [BDAD] MDM3315_rootfs.tar.bz2 (53244079)...Saved.
Jan 1 00:34:41 (none) user.notice root: SavePackage: [575F] package_summary.xml (1176)...Saved.
Jan 1 00:34:41 (none) user.notice root: SavePackage: [632E] image.bin (16163974)...Saved.
Jan 1 00:34:41 (none) user.notice root: SavePackage: [CFF5] sw_compat (2)...Saved.
Jan 1 00:34:41 (none) user.notice root: SavePackage: [1814] urp_1.0.0.0-208_v3315.tar.xz (13413600)...Saved.
Jan 1 00:34:41 (none) user.notice root: SavePackage: [68AD] package_install.sh (43300)...Saved.
Jan 1 00:34:41 (none) user.notice root: SavePackage: [50BB] package.signatures (6605)...Saved.
Jan 1 00:34:41 (none) user.notice root: SavePackage: [000F] package.sig (6561)...Saved.
Jan 1 00:34:41 (none) user.notice root: SUCCESS saved package contents to ./
Jan 1 00:34:41 (none) user.notice root: Unpacking complete.
Jan 1 00:34:41 (none) user.notice root: Starting installation
    
```

Figure C-11. Viewing Syslog Messages

- Wait until you see messages that indicate the installation is complete, as shown in the following example, and click **Install Evolution** to return to the Evolution software installation page.

```

Jan 1 00:35:27 (none) user.notice root: Checking free space: DONE
Jan 1 00:36:12 (none) user.notice root: Installing tar archive: MDM3315_rootfs.tar.bz2: DONE
Jan 1 00:36:13 (none) user.notice root: Create directories in /tmp/temp/mntPoint.cb5W4L. NONE
Jan 1 00:36:13 (none) user.notice root: Installing files in /tmp/temp/mntPoint.cb5W4L.
Jan 1 00:36:13 (none) user.notice root: /etc/idirect-release DONE
Jan 1 00:36:13 (none) user.notice root: /pkg/v3315_MDM3315_rootfs_ert_4.3.0.0-250/version DONE
Jan 1 00:36:13 (none) user.notice root: /pkg/v3315_MDM3315_rootfs_ert_4.3.0.0-250/package_summary.xml DONE
Jan 1 00:36:13 (none) user.notice root: Create required sym-links: NONE
Jan 1 00:36:13 (none) user.notice root: Skipping SSH key setup: DONE
Jan 1 00:36:13 (none) user.notice root: Skipping SSH config: DONE
Jan 1 00:36:13 (none) user.notice root: Enabling Unified Recovery Partition: DONE
Jan 1 00:36:13 (none) user.notice root: Changing slot (dual personality) but ensuring same mode
Jan 1 00:36:14 (none) user.notice root: DONE
Jan 1 00:36:14 (none) user.notice root: Running package postinstall scriptlet:
Jan 1 00:36:15 (none) user.notice root: Board Model: 177
Jan 1 00:36:15 (none) user.notice root: Selected Remote type is 3315
Jan 1 00:36:15 (none) user.notice root: Setting up MPL files...
Jan 1 00:36:15 (none) user.notice root: Boot dir is /tmp/temp/mntPoint.cb5W4L/boot
Jan 1 00:36:16 (none) user.notice root: /tmp/idirect_flash_updater-XXXXhM67Va/Fpga_mdm3315_01.core.rbf.mkimage successfully moved
/tmp/temp/mntPoint.cb5W4L/boot/fpga.core.mkimage
Jan 1 00:36:16 (none) user.notice root: Writing /tmp/idirect_flash_updater-XXXXhM67Va/Fpga_mdm3315_01.periph.rbf.mkimage to /dev/rx
Jan 1 00:36:17 (none) user.notice root: Validating /tmp/idirect_flash_updater-XXXXhM67Va/Fpga_mdm3315_01.periph.rbf.mkimage writer
Jan 1 00:36:19 (none) user.notice root: /tmp/temp/image.bin successfully moved to /tmp/temp/mntPoint.cb5W4L/boot/image.bin
    
```

Figure C-12. Syslog Messages - Installation Complete

- Click **Reset** if you wish to return all inputs on the modem to default settings.




Figure C-13. Reset Button

13. Boot the software package to the partition where you placed the software package. In this example, the software package was placed in partition 3 (Release3), so it is booted to that partition.




Figure C-14. Evolution Software Package Boot Release

14. The URP confirms that it is booting the software package to the specified partition.




Figure C-15. URP Started Installation Message

15. Log into the Terminal WUI at 192.168.1.1, using the default password.
16. Click **Administration > Software and Configuration**. The **Manage Software Packages** page is displayed (Figure 2-11). Confirm that the new software package was installed in the correct partition.

ST Engineering iDirect

13861 Sunrise Valley Drive, Suite 300

Herndon, VA 20171-6126

+1 703.648.8000

+1 866.345.0983

www.idirect.net